

# Steering

Section 6	Group 64
--------------	-------------

## Repairs and maintenance

Steering 1975- 240/260
------------------------------

# VOLVO

# Contents

	Op.	Page
<b>Specification</b> .....		2
<b>Special tools</b> .....		5
<b>Service procedures</b>		
Replacing steering column or steering lock .....	A1-A43	9
Manual steering gear, removal .....	B1-B6	16
<b>Steering gear type Cam Gear:</b>		
Disassembly .....	C1-C13	17
Illustration .....		21
Assembly .....	D1-D21	22
<b>Steering gear type ZF:</b>		
Disassembly .....	E1-E12	27
Illustration .....		30
Assembly .....	F1-F20	31
Manual steering gear, installation .....	G1-G8	36
Power steering gear, removal .....	H1-H8	38
<b>Power steering gear type Cam Gear:</b>		
Disassembly .....	I1-I25	40
Illustration .....		47
Assembly .....	J1-J52	49
Installation .....	K1-K6	61
Adjusting balance .....	K7-K27	63
Installation continued .....	K28-K39	68
<b>Power steering gear type ZF:</b>		
Checking balance .....	L1-L6	71
<b>Power steering pump Saginaw:</b>		
Disassembly .....	M1-M11	73
Illustration .....		76
Assembly .....	N1-N12	77
<b>Power steering pump ZF:</b>		
Disassembly .....	O1-O9	80
Illustration .....		83
Assembly .....	P1-P14	84

**TP 30001/3**

4500.8.84

Printed in U.S.A.


We reserve the right to make alterations



# Group 64

## Steering


1975-



VOLVO PARTS  
1 060 19748  
(107:1)

# Specifications

## Front end alignment



Vehicles unloaded

129581

### Toe-in

The toe-in should be set as follows:

	angle 2 <i>a</i>	A-a	B-b	C-c
Manual steering	24' ± 8'	4.5 ± 1.6 mm	3.5 ± 1 mm	2.5 ± 1 mm
		3/16" ± 1/16"	9/64" ± 1/32"	3/32" ± 1/32"
Power steering	16' + 8'	3.0 ± 1.5 mm	2.0 ± 1 mm	1.5 ± 1 mm
		1/8" ± 1/16"	5/64" ± 1/32"	1/16" ± 1/32"

Vehicle should not be loaded. Measurements must be made at center (hub) height. *a* is an angle, read on certain instruments. A, B, and C refer to tire outer diameter, tire inner shoulder and rim, respectively.

**Caster** (not to exceed 1/2° difference between sides) ..... +2° to +3°  
 with power steering ..... +3° to +4°

**Camber** (difference not to exceed 1/2° between left and right side) ..... +1° to +1½°



**Manual steering gear, Cam Gear**

Type .....	Rack and pinion	
No of turns from lock to lock .....	4.34	
Ratio .....	21.4:1	
Pinion: pre-tension .....	0,1 mm	0.004"
shims available .....	0.127 mm	
	0.191 mm	
	0.254 mm	
Clearance between pre-tensioning piston and cover ....	0.002-0.15 mm	0.0008-0.006"
Shims available .....	0.127 mm	
	0.254 mm	
	0.381 mm	
	0.508 mm	
Pre-tension pinion to rack .....	0.6-1.7 nm	0.44-1.25 ft.lb.
Lubricant (grease) .....	Volvo P/N 1161001	
Quantity .....	75 grams	2.5 oz.

**Manual steering gear, ZF**

Type .....	Rack and pinion	
No. of turns from lock to lock .....	4.34	
Ratio .....	21.4:1	
Pre-tension pinion to rack .....	0.6-1.7 Nm	0.44-1.25 ft.lb.
Lubricant .....	Volvo P/N 1161001	
Quantity .....	75 grams	2.5 oz.

**Power steering gear, Cam Gear (Early type)**

Type .....	Rack and pinion	
No. of turns from lock to lock .....	3.5	
Ratio .....	17.2:1	
Pinion: gaskets for pinion pre-tension .....	P/N 1206931, 1206934	
Clearance between pre-tensioning piston and cover ....	0.05-0.15 mm	0.002-0.006"
Shims available .....	0.051 mm	
	0.089 mm	
	0.127 mm	
	0.254 mm	
Pre-tension pinion to rack .....	0.9-1.7 Nm	8-15 in.lbs.
Checking balance:		
- Power pump pressure .....	1.2 MPa	170 psi
- at torque reading .....	3.5-5.0 Nm	30-40 in.lbs.
Difference between sides must not exceed .....	1.0 Nm	0.73 ft.lb.
Lubricant ("Lubricant for steering gear") .....	Volvo P/N 1161001-1	
Quantity .....	0.2 liter	0.2 qt.
Power pump oil .....	ATF	
Quantity: integrated oil reservoir .....	0.7 liter	0.65 qt.
separate oil reservoir .....	1.2 liter	1.1 qt.

## Specifications

### Power steering gear, ZF (Fixed Valve Housing)

Checking balance:

- Power pump pressure .....	2.0 MPa	285 psi
- at torque reading .....	4-5.5 Nm	35-40 in.lb.
Difference between sides must not exceed .....	0.5 Nm	4.4 in.lb.

### Power steering pump, ZF

Type .....	Vane pump	
Max. pressure, early prod. ....	7.5 MPa	1070 psi
late prod. ....	5.8 MPa	820 psi
Theoretical capacity at 500 rpm .....	6.65 liter/min	6.24 qt/min
Drive .....	Belt drive	
Drive ratio, engine to pump .....	1:1	

### Power steering pump, Saginaw

Type .....	Vane pump	
Max. pressure .....	5.5-7 MPa	780-995 psi
Theoretical capacity at 500 rpm .....	5 liter/min	5.3 qt/min
Drive .....	Belt drive	
Drive ratio, engine to pump .....	1:0.9	

## Torques

### Steering

	Nm	ft.lb.
Steering wheel center nut .....	60±15	44±11
Screws, steering column attachment .....	20±5	14±4
Screws, steering shaft rubber coupling .....	20±5	14±4
Screws, steering shaft joint .....	23±5	17±4
Screws and nuts, steering gear to front axle .....	20±5	14±4
Nut, tie rod to ball joint .....	70±10	51±7

### Manual steering gear, ZF

Pinion nut .....	24±2	17±1.5
------------------	------	--------

### Manual steering gear, Cam Gear

Screws, pinion cover .....	19±2	14±1.5
Screws, pre-tensioning device cover .....	19±2	14±1.5

### Power steering gear, Cam Gear


Screws, pre-tensioning device cover .....	19±2	14±1.5
Screws, upper pinion cover .....	19±2	14±1.5
Screws, lower pinion cover .....	19±2	14±1.5
Lock screws, outer tube to housing .....	19±2	14±1.5
Lock nut, pinion .....	14±1	10±0.75
Fittings, pressure hoses and return hoses .....	42±7	30±5




# Special tools

When ordering tools, put 999 in front of 4-digit tool number.


<b>1801</b>	<b>Standard handle</b>	<b>5051</b>	<b>Puller</b> bearing and seal
<b>1819</b>	<b>Bearing puller</b>	<b>5052</b>	<b>Drift</b> installing bearing
<b>2263</b>	<b>Steering wheel puller</b>	<b>5053</b>	<b>Adapter</b> checking pinion torque
<b>2520</b>	<b>Work stand</b>	<b>5054</b>	<b>Cover</b> adjusting balance
<b>2734</b>	<b>Drift</b> installing seal	<b>5055</b>	<b>Pressure gauge</b> balance and oil pressure
<b>2863</b>	<b>Drift</b> installing seal	<b>5056</b>	<b>Sleeve</b> installing seal
<b>2993</b>	<b>Drift</b> installing rack bushing Cam Gear manual steering gear	<b>5119</b>	<b>Wrench</b> lock nut, pinion upper bearing, ZF steering gear
<b>4078</b>	<b>Puller</b> rack bushing	<b>5175</b>	<b>Nipple</b> checking balance
<b>5043</b>	<b>Puller</b> tie rod end	<b>5176</b>	<b>Nipple</b> checking balance
<b>5046</b>	<b>Fixture</b> steering gear overhaul	<b>5179</b>	<b>Adapter</b> checking balance
<b>5047</b>	<b>Puller</b> for bearing	<b>5182</b>	<b>Adapter</b> installing cover
<b>5048</b>	<b>Drift</b> installing bearing	<b>9177</b>	<b>Torque gauge</b>
<b>5049</b>	<b>Sleeve</b> adjusting balance		



1810 Standard handle




1819 Bearing puller




2263 Steering wheel puller

## Special tools




**2520 Work stand**  
**5046 Fixture**  
steering gear overhaul




**2734 Drift**  
installing seal




**2863 Drift**  
installing seal




**2993 Drift**  
installing rack bushing,  
Cam Gear




**4078 Puller**  
rack bushing




**5043 Puller**  
tie rod end



**5047 Puller**  
for bearing



**5048 Drift**  
installing bearing




**5049 Sleeve**  
adjusting balance







**5051 Puller**  
bearing and seal




**5052 Drift**  
installing bearing




**5053 Adapter**  
checking pinion torque  
**9177 Torque gauge**




**5054 Cover**  
adjusting balance




**5055 Pressure gauge**  
balance and oil pressure  
**5175 5176 Nipples**  
checking balance




**5056 Sleeve**  
installing seal




**5119 Wrench**  
lock nut, pinion upper  
bearing, ZF



**5179 Adapter**  
checking balance



**5182 Adapter**  
installing cover


1976—  
1977



# Replacing steering column or steering lock

## Special tools:

2263 Steering wheel puller (1976–1978)  
Deep thin wall socket (1979–)




A1

**Disconnect the battery ground cable.**

A2

**Disconnect the upper joint from the upper and lower steering shafts.**

Use a screwdriver to open the flange joint so it comes loose from the upper steering shaft.



A3

**Remove the steering wheel.**

Use a screwdriver to pry loose the steering wheel pad.

Use steering wheel puller 2263 to remove the steering wheel. Do not knock on the steering wheel or puller as this may deform the crumple-zone unit in the upper section of the steering shaft.

**Note:** from 1979 year Model no puller is needed. Use a deep thin wall socket to remove the steering wheel nut and pull the steering wheel UP.

A4

**Remove upper and lower column covers.**


A5


**Remove the retainer for the wiper and turn signal switches.**

Disconnect the connector for the wiper switch. Remove the two screws for the switch retainer. Lift the retainer up over the shaft end.

A6

Remove the panel under the instrument panel. Remove the side panel at the center console.






A7

**Disconnect the connector at the steering lock.**

A8

**Remove the steering lock retaining screws.**

Drill holes in the screw centers. Use fitting screw extractor to remove the screws.




A9

**Remove the defroster hose.**

A10


**Remove the lower retainer bracket for the steering column.**



A11

**Remove the steering column.**

Push it forward to disconnect the rubber seal. Then lower it and pull it out.



A12

**Remove the steering lock.**

Use the key to unlock the lock. Remove the retaining screws.



A13

### Check the steering column .


Check that the upper crumple zone is intact. Its upper end (A) should not move axially in relation to the lower end (B).

The overall length of the steering column should be:

Models:

1976-1978  $689 \pm 1$  mm = 27.126"  $\pm 0.04$ "

1979-  $704 \pm 1$  mm = 27.717"  $\pm 0.04$ "




113 230

A14

### Install the steering lock .

Position the lock so that the distance between the lock upper part and the end of the tube is 97 mm = 3.82".




125 533

A15

### Check the two plastic guides .

They must be provided with spacers and turned so that the washers are DOWN.




125 534


A16

### Position the steering column .

Screw in the shearing bolts but do not tighten.




1196 650



A17

### Install the lower attachment.


First fit the rubber spacer and then the clamp.  
Do not tighten the screws fully.



A18

### Adjust the steering column position.

The lock should be  $15 \pm 1.5 \text{ mm} = 0.59'' \pm 0.06''$  from the dashboard. Measure at position II on the lock.




A19

### Check position of steering column.

The steering column must not contact the upper attachment plastic guides as this can cause noise.

If the steering column is incorrectly positioned, adjust the dashboard beam location. Release the beam retaining screws, adjust the beam to correct position and tighten the retaining screws again.



A20

### Tighten the upper attachment.

DO NOT shear the shearing bolts at this moment.

A21


### Tighten the lower attachment.

Torque  $20 \pm 5 \text{ Nm} = 14 \pm 4 \text{ ft.lbs.}$

A22

### Position the defroster hose.






A23

**Position the rubber seal on the dashboard. Loosely fit the upper joint on the upper steering shaft .**

A24

**Attach the lower steering shaft flange to the upper joint .**

Torque:  $23 \pm 5$  Nm =  $17 \pm 4$  ft.lbs.



A25

For 1979 and later Models  
and for 1978 Models equipped with ZF power  
steering gear:

**Check steering shaft .**

Following any repair to the steering shaft.

The distance A between the upper joint and the  
shoulder on the lower steering shaft should be:

when checking 10–19 mm = 0.40–0.75"

15 mm = 0.60"

If incorrect, the distance should be adjusted as fol-  
lows:

A26

**Pull up the protection for the lower joint.**

(Not power steering equipped.)

A27

**Loosen the joints.**

Loosen the screws B at the lower joint and C at  
the upper joint just so much that the screw head  
comes free from the joint.

A28

**Adjust the distance A .**


Move lower shaft up or down. Be careful not to  
change the position of the upper steering shaft as  
it will influence the distance between the steering  
wheel and the covers.


A29

**Retighten the joints .**

Torque:  $23 \pm 5$  Nm =  $17 \pm 4$  ft.lbs.

Refit the lower joint protection (not vehicles with  
power steering).





128 598

A30

### Adjust distance between steering wheel and steering wheel cover.

Operations A25–A29 must be completed.

A31

### Pull up the protection for the lower joint.

A32

### Loosen lower joint.

Loosen the screw B at the lower joint just so much that the screw head comes free from the joint.

A33

### Adjust distance E.

Move the lower steering shaft to obtain a clearance of 1–2 mm = 0.04–0.08" between the steering wheel and the covers.

A34

### Retighten the joint.

Torque:  $23 \pm 5$  Nm =  $17 \pm 4$  ft.lbs.

Refit the lower joint protection.

A35

### Attach the switch retainer. Reconnect the wires.


Use one of the retaining screws to attach the ground wire.

A36

### Reconnect the wire connector.


A37

### Install upper and lower steering column covers.



126 528






A38

**Position spring seat and spring. Install the steering wheel.**

Observe correct steering wheel spoke position.

Torque  $60 \pm 15$  Nm =  $44 \pm 11$  ft. lbs.




A39

**Shear the shearing bolts.**

A40

**Install side panel and panel under the instrument panel**



A41

**Tighten the screw for the upper joint flange.**

Torque:  $25 \pm 5$  Nm =  $18 \pm 4$  ft.lbs.

A42

**Reconnect the battery ground cable. Test operation.**


A43

**Remedy in case of rattle at the steering shaft bearings.**

The bearing pre-tension should be increased by installing one (in severe cases two) washer on top of the spring.

Use steering wheel puller 2263 for 1976-1978 Models.

For 1979 Models and on a deep thin wall socket is used to remove the steering wheel nut. The steering wheel can be removed without steering wheel puller.




## Manual steering gear

### Removal

#### Special tool:

5043 Tie rod end puller




B1

#### Disconnect the steering shaft flange at the steering gear.

Remove the clamp screw. Use a screwdriver to open the flange.

Late versions have a plastic protection cover for the joint. Push it up to gain access to the lower joint.




B2

#### Place the front end on stands.

B3

#### Mark and remove the front wheels.

Mark the rim relative to the screws to avoid re-balancing.




B4

#### Disconnect the tie rod ends.

Remove the retaining nuts. Use tool 5043 to disconnect the tie rod ends.






B5

**Disconnect the steering gear at the front axle beam.**

First remove the splash shield under the engine. Save rubber spacers and plates.



B6

**Disconnect the steering gear at the steering shaft flange. Remove the steering gear.**

Save the dowel pins.

## Steering gear type Cam Gear Disassembly

### Special tools:


2520 Work stand  
2734 Drift  
4078 Puller  
5046 Fixture  
5047 Drift

### Cleanliness

#### CAUTION

Do not allow dirt or foreign matter to come in contact with power steering components. Contamination will cause malfunction of the system or leaks causing unnecessary repairs.


Repairs to the power steering system should be accomplished in a dirt and dust free area. Clean components thoroughly before disassembly.



C1

**Install the steering gear on a stand.**

Use stand 2520 and fixture 5046. Use the U-bolt from the vehicle.



C2


**Clean the exterior of the steering gear. Check inner and outer joints for wear.**



C3

**Disconnect the rubber bellows at the steering gear housing.**


Early type steering gears: collect the oil in a pan.



C4

**Bend up locked portion of ball joints.**

Use a narrow chisel.



C5

**Remove both tie rod ends.**


Use a 18 mm =  $23/32$ " wrench to hold the rack on the outermost tooth.

Use a 32 mm =  $1-9/32$ " wrench to turn the ball joint.



C6


**Remove the cover for the pre-tensioning device.**



C7


**Remove spring, piston and O-ring.**

No O-ring on steering gear lubricated with grease.




C8


**Remove pinion cover.**



C9


**Remove pinion and spacer sleeve.**





C10


**Pull out the rack toward the pinion side of the steering gear.**



C11


**Remove rack bushing.**

Use puller 4078.



**Remove pinion lower bearing.**

Use puller 5047 or 1819 as applicable.



C13

**Clean, check, replace parts.**

Always replace rack bushing and seals.

Replace both pinion bearings if they are early type. Late type bearings are equipped with plastic ball retainers which prevent steering gear seizure.



1

## Steering gear

### Cam Gear

# Steering gear type Cam Gear

## Assembly


### Special tools:

2734 Drift  
2993 Drift  
5048 Drift  
5053 Adapter  
9177 Torque meter

### Lubricant:

Grease P/N 1161001-1 (approx. 100 grams = 3.5 oz.)


D1



### Install the rack.

Position bushing so that locks align to housing slots.  
Use drift 2993 to install the bushing.


D2



### Install pinion lower bearing.

Use drift 5048.


D3



### Position pinion and upper bearing assembly in the housing.

**Note:** no shims on the upper bearing.






125 411

D4

**Position the spacer sleeve on top of the bearing.**




125 412

D5

**Install the cover. Use dial gauge to measure pinion end play.**

The cover should be installed **with** gasket and **without** seal.



125 413


D6

**Remove the cover. Remove the pinion.**

D7

**Determine amount of shims.**

The shim thickness should equal the measured end play, plus 0.1–0.0025 mm for pre-tensioning.




125 414

D8

**Install pinion cover seal.**

Use drift 2734.



D9


### Lubricate rack, pinion and bearings.

Use approx. 75 grams = 2.5 ozs. of Volvo P/N 1161001. Lubricate the parts carefully. Fill excess grease in the rubber bellow.

D10

### Install the rack.

Insert the rack from the pinion side. Be careful not to damage the bushing by the rack teeth.




D11

### Position the rack. Install the pinion.

Adjust the rack to protrude 72 mm = 2-7/8".


Install the pinion. The pinion should have one of the three positions shown.



D12

### Install shims and spacer sleeve.

The shims should be located between the upper bearing and the spacer sleeve.




D13

### Install pinion cover with gasket.

Torque:  $19 \pm 2$  Nm =  $14 \pm 1.5$  ft.lbs.






D14

**Install the pre-tensioning piston in the housing and determine clearance.**

The piston should be without O-ring and spring. Use feeler gauge and ruler to determine the clearance from the piston end to the housing surface.


Move the rack from end to end and measure at the position where the largest clearance is obtained.



D15

**Determine shims and gasket.**


Shims and gasket should together equal determined clearance plus 0.05—0.15 mm = 0.002—0.006."



D16

**Install spring and O-ring in the piston.**


No O-ring on steering gear lubricated with grease.



D17

**Install cover with shims and gasket.**

Torque:  $19 \pm 2$  Nm = 14–1.5 ft.lbs.



D18


### Check pinion torque.

Use adapter 5053 to attach torque meter 9177 to the pinion shaft. Crank back and forth between end positions.

Torque: 0.6–1.7 Nm = 5–15 in.lb.

If torque in any place is excessive, stop rack in that position and readjust pretensioning device.

If rack jams with the pre-tensioning device removed, it is warped and should be replaced.




D19

### Attach the steering rods.

If using the old rods, swap left and right side rods to obtain new position of the lock. alternately, a washer max. 0.25 mm = 0.01" can be placed between the rod and the rack.

Use a 18 mm wrench to hold on the outermost tooth of the rack.


Use a 32 mm wrench to turn the nut.



D20

### Lock the ball joint.

Punch the ball joint edge into the rack groove.



D21

### Attach rubber bellows.

Attach outer ball joints (if removed).



# Steering gear type ZF

## Disassembly

### Special tool:


5119 Wrench

### Cleanliness

#### CAUTION

Do not allow dirt or foreign matter to come in contact with power steering components. Contamination will cause malfunction of the system or leaks causing unnecessary repairs.

Repairs to the power steering system should be accomplished in a dirt and dust free area. Clean components thoroughly before disassembly.




125 429

E1

**Clean the steering gear exterior.  
Install the steering gear in a vise.  
Check the ball joints.**

Use a vise with soft jaws.  
Check inner and outer ball joints for wear.




125 430

E2

**Remove the rubber bellows.  
Bend up the steering rod locks.**

The rubber bellows are held in place by flanges. Use hands to pull them loose.




125 431

E3

**Remove the steering rods.**


Use a 22 mm = 7/8" wrench to hold on the outermost tooth of the rack.

Use a 27 mm = 1-1/16" wrench to unscrew the joint.



E4


**Remove the dust seal over the pre-tensioning device.**



E5

**Remove the cotter pin.  
Remove the cover.**


Use wrench 5 119. Save the spring inside the cover.



E6

**Remove the pre-tensioning piston.**


Removal might be facilitated by knocking rack with palm.



E7

**Remove pinion dust seal.**






### Remove the pinion nut.

Use wrench 5119.  
First remove any lock installed.


E8



### Remove the pinion.

Clamp the pinion shaft in a vise with soft jaws. Tap lightly on the housing with a plastic-tip mallet.


E9



### Remove the rack. Remove the rack bushing.

Press in the locking tabs. Use a narrow screwdriver to pry out the bushing.

E10



### To replace the pinion bearing:

Remove thrust washer and lock ring.  
Press loose the pinion bearing.


E11

### Clean all parts. Check for wear.

Replace all O-rings and any worn parts.

E12

# Steering gear ZF



VOLVO PARTS  
1 060 23324  
(107:3)



# Steering gear type ZF


## Assembly

### Special tools:

5053 Adapter  
5119 Wrench  
9177 Torque meter

### Lubricant:

Grease P/N 1161001-1




125 439

F1

Press the bearing onto the pinion.

F2


Install lock ring and thrust washer.



125 440

F3

Install new O-rings on the rack bushing.




125 441

F4

Install the rack bushing.

Make sure the locking tabs of the bushing fit correctly in the housing recesses.

F5




125 442

### Lubricate and install the rack.

Use grease P/N 1161001.

Insert rack in pinion side of housing. Be careful not to damage the bushing with the rack teeth.

F6



125 443

### Lubricate the pinion.

Fill the bearing with grease.


F7

### Position the rack. Install the piston.

Adjust the rack to protrude 73 mm = 2.874".

Install the pinion. It should have one of the positions shown.


F8



125 444

### Install a new O-ring in the pinion nut.

F9



125 445


### Install lock plate and pinion nut.

Use wrench 5119.

Torque:  $24 \pm 2$  Nm =  $17 \pm 1.5$  ft.lbs.

Lock plate should always be used, also if it was missing at disassembly. Lock the lock plate tab.






125 446

**F10**

**Fill grease and install the dust seal.**


Fill the space on top of the nut with the grease, P/N 1161001. Install the dust seal.



125 447

**F11**


**Install a new O-ring on the pre-tensioning piston.**



125 448

**F12**

**Lubricate the pre-tensioning piston. Install piston and spring.**




125 433

**F13**

**Install the cover for the pre-tensioning piston.**

Use wrench 5119. Do not tighten the cover fully.



F14


### Check pinion torque.

Use adapter 5053 to attach torque meter 9177 to the pinion shaft. Crank back and forth between end positions.

Torque: 0.6–1.7 Nm = 5–15 in.lb.


Tighten the pre-tensioning piston cover to obtain correct pinion torque.

If the rack jams with the pre-tensioning piston removed, it is warped and should be replaced.




F15

### Use a cotter pin to lock the piston cover.



F16

### Install the dust seal.



F17

### Lubricate the steering gear.


Crank out the rack fully. Fill teeth spaces with grease P/N 1161001. Crank in the rack.

Repeat this procedure.

Fill excess grease in the rubber bellow.

This procedure in addition to previous lubrication of parts will result in a grease charge of approx. 75 g = 2.5 ozs.






F18

### Install steering rods.


Use new lock washers. Use a 22 mm = 7/8" wrench to hold on the outermost tooth of the rack.

Use a 27 mm = 1-1/16" wrench to tighten the joint.



F19

### Lock the washers.




F20

### Install the rubber bellows.

# Manual steering gear

## Installation on vehicle




G1

### Prepare the steering gear for installation.

Install the rubber spacers and plates at the steering gear attachment points.


Remove the dowel pins if a new steering gear with dowel pins should be installed on a vehicle without holes for the dowel pins.



G2

### Position the steering gear.

Guide the pinion shaft in.




G3

### Attach the steering gear to the front axle member.

Make sure the U-bolts are aligned in the plate slots. Install flat washers and nuts.


Torque:  $20 \pm 5$  Nm =  $14 \pm 4$  ft.lbs.





G4

**Install the splash shield under the engine.**



G6

**Attach the steering rods to the steering arms.**


Torque:  $60 \pm 10$  Nm =  $44 \pm 7$  ft.lbs.

G6

**Install front wheels, lower vehicle.**

Use the marks to install the wheels on previous locations.

Torque:  $120 \pm 20$  Nm =  $88 \pm 15$  ft.lbs.



G7

**Tighten the steering shaft joint.**

Torque:  $25 \pm 5$  Nm = ft.lbs.

Check/adjust the steering gear according to instructions in op. A25-A34, this manual.



G8

**Check/adjust toe-in.**

Use rust protective oil to protect the steering rod threads.

Lock nut torque:


$70 \pm 10$  Nm = ft.lbs.

# Power steering gear

## Removal

### Special tool:

5043 tie rod end puller



H1

**Disconnect the steering shaft flange at the steering gear.**

Remove the clamp screw. Use a screwdriver to open the flange.



H2


**Place the front end on stands.**

Use the front jack supports.

H3

**Mark and remove the front wheels.**

Mark the rim relative to the screws to avoid re-balancing.




H4

**Disconnect the tie rod ends.**


Remove the retaining nuts. Use tool 5043 to disconnect the tie rod ends.





H5

**Remove the front guard plate.**




H6

**Disconnect the hydraulic hoses at the steering gear.**

On 260 late production, the clamp retaining the pressure hose at the front axle member must be removed.


Install protection plugs in the hose connections.



H7

**Remove the steering gear.**

Remove the retaining screws. Remove the steering gear. Save the spacers.



H8

**Take out the steering gear.**

Pull the steering gear down until free from the steering shaft joint. Then take it out on the left side. Save the dowel pins.

# Power steering gear type Cam Gear.

## Disassembly

### Special tools:

1801 Pull hammer  
2520 Work stand  
5046 Fixture  
5049 Sleeve

### Cleanliness

#### CAUTION

Do not allow dirt or foreign matter to come in contact with power steering components. Contamination will cause malfunction of the system or leaks causing unnecessary repairs.


Repairs to the power steering system should be accomplished in a dirt and dust free area. Clean components thoroughly before disassembly.

I 1

### Install the steering gear on a stand.

Use work stand 2520 and fixture 5046.


Use a U-bolt from the vehicle.



I 2

### Clean the exterior of the steering gear.

Check inner and outer joints for wear




I 3


### Disconnect the rubber bellows from the steering gear.

### Drain the lubricant.

Early type steering gears: collect the oil in a pan.








I4

**Remove the tie rods.**


Use a 7/8" wrench to hold the rack on the outermost tooth.

Use a 30 mm 1-3/16" wrench to turn the joint.



I5


**Remove the oil tubes.**



I6


**Remove the pre-tensioning device.**

Remove cover, piston, O-ring and spring.



I7


**Remove the lower pinion cover.  
Remove the spacer sleeve.**



I8

**Bend up the locking tab.  
Remove the nut.**

Use adapter 5053 to hold the outer end of the shaft. The valve should not move axially when removing the nut.




I9

**Remove inner race with ball retainer and  
the cup.**

Use tool 5049

**Note:** be sure to count the number of turns in order to obtain same pinion height when reinstalling.



I10

**Remove the valve housing cover.**

Remove the outer dust seal.




I11

**Disassemble the valve housing.**


Remove the spring. Lift up the valve housing and the pinion.

Be careful not to damage valve and valve housing.







**I 12**  
**Remove the lock screw for the right side housing. (note aluminum spacer washer)**



**I 13**  
**Pull off right side housing and connecting tube.**




**I 14**  
**Pull out the rack and pinion sleeve.**



**I 15**  
**Remove the lock screw for the left side housing.**


**Note:** special sealing washer with rubber insert.



I16

**Pull out the outer tube.**


Check that outer tube and O-ring make good contact.  
(Slight resistance when removing).



I17

**Pull out the inner tube.**


Check that inner tube and O-ring make good contact.



I18

**Remove upper bearing and pinion seal.**

Use pull hammer 1819.




I19

**Remove lower bearing race.**


As necessary and only if the bearing is replaced.  
Use two narrow screwdrivers to remove the race.






I20

Remove the left housing from the fixture.  
Remove the O-rings and the protection  
plug.




I21

Right housing: remove O-rings and  
spacer sleeve.



I22


Bearing sleeve: remove inner and outer  
seals and O-rings.



I23

**Piston seal.**

Replace if damaged or if the vehicle mileage exceeds  
40,000 km (25,000 miles).




125 623

I24

### Inner tube.

Remove snap ring, spacer washer and seal.



125 624

I25

### Clean, inspect, replace.

Replace all seals, O-rings and the valve cover assembly. Piston seal: see step I23.

If the pinion, control valve or valve housing is damaged, replace the parts as an assembly.

The rack bearing assembly should be replaced if the bushing is damaged.