


## Cylinder head, assembly

Special tools: 5021, 5025, 5034, 5219, 5222

### Location of senders/contacts on cylinder head and block

C45

All senders/contacts are located on the left-hand side of the cylinder head and block.



#### F engines USA 1981–1985

Make sure that the connectors for the start injector, CIS system temperature sender and LH-Jetronic temperature sender are correctly connected.

The connectors look alike and can easily be interchanged.

Engine type	Temperature sender CIS (blue & red)	Thermostat valve EGR (black hoses)	Thermostat valve acceleration enrichment (black hoses)	Temperature sender gauge (yellow)	Thermal time-switch, start injector (blue-yellow & white)	Temperature sender LH-Jetronic (blue & black)	Thermal contact, Lambda-sond (green)	Knock sensor ignition (brown)
B 17, 19, 21, 23 A 1975–1984	—	2 <sup>3)</sup>	—	3	—	—	—	—
B 19 K 1984	—	—	—	3	—	—	—	—
B 19, 21, 23 E 1975–1984	—	2 <sup>3)</sup>	—	3	5	—	—	—
B 19, 21 E-Turbo 1981–1984	—	2 <sup>5)</sup>	—	3	4	—	—	—
B 21 F-5 <sup>1)</sup> 1976–1984 1981 USA	— 1 <sup>4)</sup>	2 <sup>3)</sup> —	— 2	3 3	5 5	— —	— —	— —
B 21 F-9 <sup>2)</sup> 1981 1982	1 1	— —	2 2	3 3	5 5	— —	— 7	— —
B 21 F-Turbo 1981 1982–1985	6 6	— —	2 2	3 3	4 4	— —	— 7	— —
B 21 FLH-Jetronic 1982	1	—	—	3	5	4	—	—
B 23 FLH-Jetronic 1983–1984	—	—	—	3	—	4	—	8


<sup>1)</sup> B 21 F-5 = CI system and Bosch ignition system

<sup>2)</sup> B 21 F-9 = CI system and Chrysler ignition system

<sup>3)</sup> Only certain year models and markets

<sup>4)</sup> Only California

<sup>5)</sup> Only B 21 ET Scandinavia and Switzerland 1984–1985



C46

#### Check valve stem position in relation to camshaft



This measurement should be carried out to ensure that there is sufficient space for valve adjustment.

Place valves in cylinder head.  
Remove measuring rings for D 20/D 24 (largest ring) from gauge 5222 and place gauge in cylinder head.  
Slide measuring ring for B 17–B 23 over valve and press valve against seat with a finger.

Ring must not touch valve. If valve touches ring the stem must be ground down.

Max grinding = 0.5 mm (0.02 in)


Min 3.5 mm (0.138 in) between valve cotter and end of valve stem.



C47

#### Install new valve stem seals

Seals are required on inlet valves only.  
Use only late type seals.



Always use the protective sleeve supplied with new parts.

To install seal:


Oil and place valve in position.

Place protective sleeve on valve stem.

Fit seal using tool 5219. The tool should abut seal flange.

Remove protective sleeve.

C48



130 093

**Install:**

- lower spring seat (1)
- spring (2)
- upper spring seat (3)
- valve cotter (4)
- rubber seal (5)


**Important:**

Two different types of springs and seats are in use, see C42.


C49

**Lubricate and install tappets and adjusting shims**

Place in same position as found.



130 138




130 139

C50

**Install:**

- belt tensioner
- thermostat + O-ring, thermostat housing and lifting eyelet
- half-moon shaped rubber seal at rear of cylinder head.







130 140

C51

**Lubricate:**

- bearing shells
- cams
- tappets and adjusting shims.



C52

### Install camshaft and caps

Place camshaft and rear bearing cap on cylinder head. Guide pin (arrowed) for pulley should face up.

Press camshaft into cylinder head with press tool 5021. (Use rear bearing cap as guide).

Do not tighten nuts on rear bearing cap fully at this stage.

Smear front bearing cap sealing face with sealer P/N 1161 027-6.

Lubricate and fit remaining bearing caps. Do not tighten nuts fully at this stage.

Remove press tool 5021.

Lubricate and fit centre bearing cap.

Torque bearing cap nuts to **20 Nm** (14 ft.lbs).

C53

### Install front oil seal

Use sleeve 5025.

Grease oil seal and shaft. Check that edges of seal are not damaged.

C54

### Install guide plates and pulley

Turn plates so that edges point away from pulley.

Torque to **50 Nm** (36 ft.lbs). Use counterhold 5034.

C55

### Valve adjustment

See operations ..... B 1-12


Page ..... 28

C56

### Install intake manifold

## Assembling, engine

Special tools: 2810, 5035



### Check position of crankshaft and camshaft

Check that:

- No. 1 piston at T.D.C.
- camshaft is at T.D.C. firing for No. 1 cylinder

C57

### Place gasket and cylinder head in position

Check that water pump O-ring sits correctly in groove.

C58

**IMPORTANT!** Do not rotate camshaft or crankshaft as pistons may strike valves.

Early type



Late type



137 541

### Torque cylinder head bolts

Two types of bolts are in use.

Do not interchange different types.


C59

#### Late type bolts:

Bolts should be replaced if center section shows signs of extension. Do not re-use bolts more than 5 times. If in doubt, fit new bolts.

Oil bolts.

Place bolts in cylinder head and tighten each bolt in sequence according to following stages.



Early-type

1 = 60 Nm (43 ft.lbs)

2 = 110 Nm (80 ft.lbs)


**Note:** Retorque early type bolts, see C9 page 54

Late-type


1 = 20 Nm (14 ft.lbs)

2 = 60 Nm (43 ft.lbs)

3 = Angle-tighten 90°



130 386



138 177

### Install timing gear belt

**Important:** Do not turn crankshaft or camshaft as pistons can strike valves and cause damage.

- Check that camshaft, intermediate shaft and crankshaft are aligned as shown adjacent.
- Place belt around crankshaft and intermediate shaft pulleys so that two lines on belt align with timing mark on crankshaft.
- Stretch belt and place over camshaft and belt tensioner.
- Check position of belt. Recheck position of pulleys.

C60

### Tighten timing gear belts


Slacken belt tensioner nut. Spring will now tension belt. Retighten nut.

C61

### Install:

- timing gear case
- fan belts. It should be possible to depress belt 5–10 mm in centre of a run
- fan shroud.

C62




118 668

### Valve adjustment

(as applicable)

See operation ..... B 1–12  
Page ..... 28

C63



C64

**Install rubber seal on rear edge of cylinder head**

C65

**Install gasket**

Check that half moon-shaped seal at rear of cylinder head is in position.

Use a new gasket.

Turbo engines require a harder type of gasket. Part number and colour of gasket are shown below.

	Colour	P/N
Turbo .....	Light beige	1326640-8
Other models .....	Blue	463999-3

C66

**Install:**

- valve cover
- ground cable
- electrical connection contact for timing advance
- nuts for valve cover, and tighten securely

C67

**Install all other parts to cylinder head and intake manifold**

A engines see below


K engines see ..... page 52

E and F engines see ..... page 52


ET and FT engines see ..... page 53

F engines with LH-Jetronic fuel systems see ... page 53

**A engines**




### K engines




---


### E and F engines




### ET and FT engines



### F engines with LH-Jetronic fuel systems





C68

#### Warm up engine


- Check/adjust ignition, idle speed and CO content.
- Check cooling system, and top up coolant if necessary.
- Adjust drive belt tension. Remove rubber plug in gear case.  
Slacken belt tensioner nut. Spring now extends belt. Retighten nut.

C69

#### Fit rubber plug

After 1000 km (600 miles):

- Check/adjust new timing gear belts.
- If new parts have been fitted to valve assembly, recheck valve clearance.




#### R retorquing cylinder head bolts

Applies only to early type bolts


1. Warm-up engine. Leave to cool for 30 minutes.
2. Slacken bolt 1 approx. 30°.  
Retorque to **110 Nm** (80 ft lbs).
3. Repeat for remaining bolts in sequence shown in illustration.

## D. Piston rings, replacement


Special tools: 5006, 5033, 5115, 5871, 2810, 5035



131 260



114 689



131 261

D1

**Remove cylinder head by method described on page 31**

D2

**Check cylinder bores**

Check for score marks and other visible damage.

If damaged, the cylinder head **must** be fitted with at least 6 bolts before lifting the engine out and reconditioning.

Engine removal, see page 83.

D3

**Remove oil sump**

See K 1-10, page ..... 78

D4


**Remove oil pump and pipe**

D5

**Rotate crankshaft**

Turn crankshaft to obtain crank pins for No. 1 and No. 4 cylinders at their lowest positions.

Check to see if caps are marked, they must not be interchanged during reassembly.



D6


### Remove connecting rod bearings and bearing shells

Check shells for score marks and other visible damage.

Do not mix up parts.

D7

Push out pistons with wooden handle of a hammer



D8

### Check and measure bearing journals

Measure for taper and out-of-round. Use a micrometer and measure at several points round the periphery and along the length.

Max. out-of-round . . . . . **0.05 mm** (0.002 in)

Max. taper . . . . . **0.05 mm** (0.002 in)

If journals are damaged or taper/out-of-round exceeds specifications, the engine must be lifted out and crankshaft replaced/reground.

**N.B.** When lifting out the engine, the cylinder head must be secured with at least 6 screws.

See page 83.

D9

### Clean cylinder bores

Push paper down into cylinder bores to prevent dirt entering crankshaft oil ducts. Clean the cylinder bores with fine emery cloth or a honing tool.


D10

### Measure cylinder bores





Use a 50–100 mm (1.97–3.94 in) hole gauge.

Measure for **maximum wear** in lateral direction of engine, just below top dead centre.

Measure for **minimum wear** in longitudinal direction of engine at bottom dead centre.



D11



### Class marking

A class letter is punched on every cylinder (C, D, E and G).

Oversizes are denoted by the abbreviation OD1 or OD2. When drilling, the new marking must be punched on.

Standard B 17, B 19	B 21	B 23
(C-marked) 88.90–88.91 (3.5027–3.503)	92.00–92.01 (3.625–3.6252)	96.00–96.01 (3.7824–3.783)
(D-marked) 88.91–88.92 (3.503–3.5034)	92.01–92.02 (3.6252–3.6256)	96.01–96.02 (3.783–3.7832)
(E-marked) 88.92–88.93 (3.5034–3.5038)	92.02–92.03 (3.6256–3.626)	96.02–96.03 (3.7832–3.7836)
(G-marked) 88.94–88.95 (3.5042–3.5046)	92.04–92.05 (3.6264–3.6268)	96.04–96.05 (3.784–3.7844)

Oversize:

OD(OS) 89.29–89.30 (3.518–3.5184)	92.5 (3.645)	96.3 (3.794)
OD(OS) 89.67–89.68 (3.533–3.5334)	93.0 (3.6642)	96.6 (3.806)

D12

### Measure piston diameter

Measure piston diameter at right angles to piston pin hole.

The diameter must be measured at different heights, according to the piston/engine type.

- B 21 A/E = 6 mm (0.236 in) from bottom
- B 23 E = 8 mm (0.315 in) from bottom
- B 23 E version 1 (piston height 80.4 mm = 3.168 in) = 15 mm (0.591 in) from bottom
- B 23 E, version 2 (piston height 76.4 mm = 3.010 in) = 8 mm (0.315 in) from bottom
- Others = 7 mm (0.276 in) from bottom

D13

### Calculate piston clearance

Example:

Measure cylinder

diameter . . . . . min 3.6256 in max. 3.6260 in

Measured piston diam. –3.6248 in –3.6248 in

Piston clearance = 0.008 to 0.0012 in

Piston clearance mm (in):

B 17 A, B 19 A/E/K,

B 21 A/E/F

0.01–0.04 (0.0004–0.0016)

B 19 ET 0.03–0.06 (0.0012–0.0024)

B 21 ET and FT 0.02–0.04 (0.0008–0.0016)

B 23 A 0.01–0.04 (0.0004–0.0016)

B 23 E version 1 (piston height

80.4 mm = 3.168 in) 0.05–0.07 (0.002–0.0028)

B 23 E version 2 (piston height

76.4 mm = 3.010 in) 0.01–0.04 (0.0004–0.0016)

B 23 F 0.01–0.04 (0.0004–0.0016)


Too large piston clearance in cylinder marked G or oversize:

D14

### Lift out engine and repair it

Before lifting it out, the cylinder head must be secured with at least 6 bolts.

See page 83.




*Excessive piston clearance in cylinders marked C, D or E*

**N.B.** Rotate crankshaft a quarter turn so that the honing tool does not strike against crank pins.

D15

### Hone cylinder bore to next oversize

Use a honing tool. Carefully wipe clean cylinder bores after honing.




### Clean and check pistons

Remove piston rings. Use a piston ring pliers. Remove all soot deposits, scrape clean piston ring grooves with a groove cleaner, for example, or with a broken, ground piston ring.

Check for:

- damage
- wear
- cracks.

D16



### Check axial clearance of piston rings

Use new piston rings.

Upper compression ring

**0.040–0.072** (0.002–0.0028)

Lower compression ring

**0.040–0.072** (0.002–0.0028)


Oil ring

**0.030–0.062** (0.0012–0.0024)

**N.B.:** The oil ring and upper compression ring are available in two versions, with different heights.

D17

If clearance is excessive, change the piston



D18

### Measure piston ring gap

Insert piston ring in cylinder bore. Use a piston turned upside down so that ring is brought into correct position.

Measure gap with the ring **15 mm** (0.591 in) above bottom of cylinder. Measure gap with a feeler gauge.

Upper compression ring


**0.35–0.65** (0.014–0.026)

Lower compression ring

**0.35–0.55** (0.014–0.022)



Oil ring

**0.25–0.60** (0.010–0.024)




### Install new piston rings

Rotate piston rings so that gaps are approx. 120° from each other.



### D20 Place bearing shells in connecting rods and in caps

Oil cylinder bores, pistons and bearing shells.




### D21 Insert no. 1 piston in cylinder

Rotate crankshaft so that crank pin for cyl. 1 points straight down.

Insert piston. Use a piston ring compressor. Push down piston with handle of a hammer.

**IMPORTANT!** The marking on the piston must point forward.




### D22 Install connecting rod cap

Check marking. The marking on the connecting rod and cap must coincide.

Oil the screws and fit **new** nuts.

Tighten:  
old bolts ..... **63 Nm** (45 ft lbs)  
new bolts ..... **70 Nm** (50 ft lbs)



128 753

D23

### Install pistons


After fitting each cap, check that crankshaft can be rotated.

D24

### Install oil pump and pressure pipe

Use new O rings.

Check that pump input shaft fits into drive shaft.



134 885

1981—


D25

### Secure drain hose from oil trap

Secure clamp to oil pump fastening screw.

Make sure that hose is securely clamped behind oil pump shoulder.

**IMPORTANT!** The hose must have an exact length, it must not be cut.




114 688

D26

### Install oil sump

By method ..... K 11—18  
page ..... 80




137 552

D27

### Install cylinder head

By method ..... C 57—69  
page ..... 49


## E. Drive belt, replacement



E1

### Remove:


- battery ground connection
- fan cover
- all drive belts from crankshaft pulley
- gear case



E2


### Basic engine adjustment

Rotate crankshaft clockwise with centre screw. Position camshaft so that marking on pulley is brought opposite marking on valve cover.



E3


### Remove pulleys from crankshaft



#### Remove drive belt


Slacken belt tensioner nut approx. 1 turn.  
Pull out belt so that belt tensioner spring is compressed.  
Retighten nut.  
Remove belt.

**IMPORTANT!** Do not rotate crankshaft or camshaft as pistons may strike against valves and cause damage.




#### Check belt tension roller

Turn roller and listen for abnormal noise from bearing.  
Check that contact face against belt is free from cracks and remains of rubber.



#### Replace belt tensioner

Operations E 6–7



#### Remove belt tensioner

First lock spring in position with a 3 mm drill.

#### Assemble and secure new belt tensioner

Use a vice. Lock spring with a 3 mm drill.


E4

E5

E6

E7

E8




130 386

### Install drive belt

**IMPORTANT!** Do not rotate crankshaft or camshaft as pistons may strike against valves and cause damage.

- place pulley in position according to marking
- place belt round crankshaft and intermediate shaft. Two lines on belt must be brought opposite marking on crankshaft.
- stretch belt and place it over camshaft and belt tensioner
- check that belt has been brought into correct position, and that markings on pulleys are opposite markings on engine.


E9



131 258

### Tension drive belt

Slacken belt tensioner nut. Spring now tensions belt. Remove locking pin (drill) from belt tensioner. Tighten nut.



131 251

### Install

- crankshaft pulleys
- gear case
- all drive belts on pulleys.  
It should be possible to depress belt 5–10 mm (0.2–0.4 in) with slight thumb pressure when correctly installed.
- fan cover
- battery ground connection

E10

E11

### Warm-up engine and check/adjust:

- ignition
- CO content
- idling.


E12

### Switch off engine

E13

### Tension drive belt

Remove rubber plug in gear case. Slacken belt tensioner nut. Spring now extends belt. Retighten nut. Fit rubber plug.




131 259

**Recheck drive belts after 600 miles (1000 km).**

## F. Camshaft, removal

Special tools: 5021, 5034




### When camshaft is replaced due to wear

It is an **absolute requirement** that the engine be **flushed clean** before new parts are fitted. Repeated damage to the tappets and camshaft have been shown to be due to engine contamination.

F1

### Flush engine clean


Change engine oil and oil filter.  
Warm up engine for approx. 10 minutes.  
Drain oil and remove oil filter.  
Replace camshaft.  
Install new oil filter and pour in oil.



F2

### Remove:


- battery ground connection
- fan cover
- fan belts
- gear case



F3

### Basic engine adjustment

Turn crankshaft clockwise with centre screw. Adjust camshaft so that marking on pulley is opposite marking on valve cover.




**F4**  
**Slacken drive belt. Lift it off from camshaft pulley**

Slacken belt tensioner nut approx. 1 turn.  
Pull out belt so that belt tensioner spring is compressed.  
Tighten belt tensioner nut.  
Lift off belt from camshaft pulley.


**IMPORTANT!**

Do not rotate crankshaft or camshaft when drive belt is removed. The pistons may strike against valves.



**F5**  
**Remove pulley from camshaft**

Use dolly 5034.




**F6**  
**Remove valve cover**

**F7**  
**Check marking on camshaft caps. Remove centre cap**

Mark caps if necessary. Carefully pry off cap with a chisel if difficult to remove.

**F8**  
**Remove camshaft**

Press down camshaft with pressing tool 5021. Remove other four caps and camshaft, with seal.




**F9**  
**Check end float of camshaft**

Place camshaft in cylinder head.  
Install rear cap.  
Slide camshaft forward and backward.  
The clearance must be **0.1–0.4 mm** (0.0039–0.0016 in).  
Measure clearance with a feeler gauge. If clearance is excessive, rear bearing cap must be replaced.

## Camshaft, installing


Special tools: 5021, 5026, 5034



### Oil:

- bearing shells
- cams
- adjustment washers on tappets.

F10



### Install camshaft and caps


Bring camshaft and rear cap (thrust bearing) into position.

Pulley guide pin must be turned upwards.

Press down camshaft with pressing tool 5021. Use rear cap as a guide.


Tighten rear cap nuts hand-tight.

F11



Coat sealing face of front cap (cylinder head side) with sealing compound, P/N 1161 027-6.

Oil and fit other three caps. Tighten nuts, hand tight at this stage.



Remove pressing tool 5021.  
Oil and install the centre cap.  
Tighten nuts **20 Nm** (14 ft lbs).

F12

### Install front sealing ring



Use sleeve **5025**.

Grease the seal and shaft. Check that rubber lip on seal is not damaged.

F13

### Install guide plates and pulley

Turn guide plates so that edges incline outwards from pulley. Tighten to **50 Nm** (36 ft lbs). Use dolly **5034**.



### Install drive belt


**IMPORTANT!** Do not rotate crankshaft or camshaft as pistons may strike against valves and cause damage.


- Place pulleys in position according to marking.
- Place belt round crankshaft and intermediate shaft. Two lines on belt must be opposite marking on crankshaft.
- Stretch belt and place it over camshaft and belt tensioner.
- Check that belt has been brought into correct position and that pulley markings are opposite markings on engine.

F15

### Tension drive belt

Slacken belt tensioner nut. Spring now tensions belt. Tighten nut.





#### Install

- gear case
- fan belts. It should be possible to depress belt 5–10 mm (0.2–0.4 in) with slight thumb pressure when correctly installed.
- fan cover
- battery ground connection

F16

#### Adjust valves clearance

Operations B2–11, page 28.

F17

#### Warm up engine and check/adjust:

- ignition
- CO content
- idling.

F18

## G. Pilot bearing in crankshaft (gearbox removed)

Special tools: 1426, 2484, 4090, 5111

Pilot bearings are installed on vehicles with manual gearboxes only. In cars with automatic transmission, there is a guide bushing in the crankshaft. The bushing is replaced by removing/installing it by hand.




#### Remove the pressure plate and driven plate

Slacken the screws alternately, a couple of turns at a time, to avoid stresses.

G1

#### Remove locking ring for pilot bearing

G2




#### Pull bearing out of crankshaft


Use extractor 4090.

G3

G4

**Install:**

- bearing in crankshaft. Use drift 1426
- locking ring.



G5

**Install driven plate and pressure plate**


Use the centering drift 2484 (early version).

Use centering drift 5111 (late version = discs with involute teeth).

Tighten screws crosswise and a couple of turns at a time so that no fractures occur.

## H. Flywheel gear ring, replacement

Only applies to cars with manual transmission. In cars with automatic transmission, the carrier plate is replaced complete with flywheel gear ring



### H1 Heat new flywheel gear ring heated to 230°C

Use a furnace or autogenous welding.

If a furnace is used, begin by inserting new gear ring in furnace. If autogenous welding is used, flywheel gear ring must be heated immediately before fitting it.


H2

### H2 Drill a hole between two teeth

Use a 10 mm (0.4 in) drill.

Drill a hole approx. 9 mm (0.35 in) deep.

**IMPORTANT!** Do not drill into flywheel, due to risk of imbalance.



### H3 Remove flywheel gear ring

Clamp flywheel in a vice with soft jaws.

Prize loose gear ring with a screwdriver. If necessary, break gear ring at drilled hole. Clean contact faces on flywheel.

H4

### H4 Heat new gear ring to approx. 230°C (446°F)

Check temperature with soldering tin (40% tin and 60% lead). Tin melts at 220–230°C (428–446°F).

H5


### H5 Fit new gear ring

Place gear ring in position.

**IMPORTANT!** The inner bevel must be turned towards flywheel.


If necessary, knock gear ring down to bottom. Use a brass drift.

Allow it to cool.



## I. Front seals for camshaft, intermediate shaft, crankshaft, replacement

Special tools: 5024, 5025, 5034




### Check that flame guard is not blocked

A blocked flame guard prevents crankcase ventilation from operating properly, and means that crankcase pressure will be too high.


Symptoms of blocked flame guard are:

- oil dipstick “jumps up” out of pipe
- oil leakage from seals in cylinder block. The seals need not always be replaced if they leak due to a blocked flame guard. Repair flame guard, clean engine and check whether seals are leaking
- engine knocks.



### Remove:


- battery ground connection
- fan cover
- all drive belts from crankshaft pulleys
- gear case.



### Basic engine adjustment

Rotate crankshaft clockwise on centre screw.

Adjust camshaft so that marking on pulley is opposite marking on valve cover.




#### Remove drive belt

Slacken belt tensioner nut approx. 1 turn.  
Pull out belt so that tensioner spring is compressed.  
Tighten belt tensioner nut.  
Remove belt.

#### IMPORTANT!

Do not rotate crankshaft or camshaft when drive belt is removed as pistons may strike against valves and cause damage.




#### Check which seal is leaking

*Camshaft and/or intermediate shaft seal, replacement*


#### Remove pulley at seal to be replaced

Use dolly 5034.



#### Remove seal to be replaced

Prize the seal carefully out with a screwdriver. The contact face must not be damaged.




#### Clean and check contact faces

(For cracks and other damage.)

#### Install new seal

Grease seal and seat.  
Use sleeve 5025 and press on seal.  
**N.B.** Check that seal is not distorted or damaged during fitting.



I 10


**Fit pulleys as applicable**

Turn guide plates of camshaft pulley so that they incline outwards from pulley.

Tighten **50 Nm** (36 ft lbs). Use dolly **5034**.

I 11

Turn intermediate shaft wheel with marking (a cavity) outwards. Tighten to **50 Nm** (36 ft lbs). Use dolly **5034**.



I 12

**Crankshaft seal, replacement****Remove:**

- centre screw. Use dolly **5034**
- pulley and the hub together
- belt, wheel and guide plates

I 13

**Remove seal**

Carefully prize out seal with a screwdriver. The contact face must not be damaged.

I 14

**Clean and check contact faces**

For cracks or other damage.


I 15


**Install new seal**

Grease seal and seat.

Press in seal. Use sleeve **5024**.

**N.B.** Check that seal is not distorted or damaged during fitting.






116

#### Install:

- guide plates and pulley.  
Plates must be turned so that edges are inclined outwards from pulley. The late version of pulley must be turned with key bevel towards engine
- belt. Two lines must be opposite mark on engine
- hub and pulleys together
- centre screw




117

#### Torque crankshaft centre screw

Use dolly 5034.

Tighten to **165 Nm** (120 ft lbs).




118

#### Install drive belt

**IMPORTANT!** Do not rotate crankshaft or camshaft as pistons may strike against valves and cause damage.


- Place pulleys in position according to marking.
- Place belt round crankshaft and intermediate shaft. Two lines on belt must be opposite marking on crankshaft.
- Stretch belt and place it over crankshaft and belt tensioner.
- Check that belt has been brought into correct position, and that markings on pulleys are opposite markings on engine.




119

#### Tension drive belt

Slacken belt tensioner nut. Spring now tensions belt. Tighten nut.



131 251



131 259

120

**Install:**

- gear case
  - all drive belts on pulleys.
- It should be possible to depress belt by 5–10 mm (0.2–0.4 in) with slight thumb pressure when correctly installed
- fan cover
  - battery ground connection

121

**Warm-up engine and check/adjust:**

- ignition
- CO content
- idling
- any leakage

122

**Switch off engine**


123

**Re-adjust drive belt**

- Remove rubber plug on gear case
- Slacken belt tensioner nut approx. 1 turn.
- Belt tensioner spring now tensions belt.
- Retighten nut.
- Install rubber plug.

## J. Crankshaft rear seal, replacement (gearbox removed)

Special tools: 1801, 2484, 5111, 5112, 5276



### Manual transmission

J1

#### Remove pressure plate and driven plate

Slacken pressure plate screws crosswise, and a couple of turns at a time, to avoid fractures.

J2

#### Remove flywheel or carrier plate

Prevent flywheel from rotating with locking sector 5112.

J3

#### Remove rear seal

Pry out seal with a screwdriver. Take care to ensure that sealing faces in holder and on crankshaft are not damaged.

#### IMPORTANT!

Note position of seal in relation to sealing flange so that the correct position is known when fitting new seal (see fig).

J4

#### Clean and check sealing faces

(In holder and on crankshaft.)

J5

#### Press seal into rear sealing flange

Assemble standard shank 1801 and drift 5276.

Oil contact face of seal against holder and sealing lips.

Thread seal onto drift.



If there is a wearing surface on crankshaft, press seal further into flange than before.

Remove **one** spacer ring from drift if old seal was placed flush with flange.


Remove **two** spacer rings from drift if old seal was 3 mm (0.1 in) inside flange.

Leave spacer rings in drift if crankshaft is undamaged.

Tap in seal until drift contacts crankshaft.



J6

**Install flywheel (manual) or carrier plate (automatic)**

Rotate crankshaft to top dead centre position for cyl. 1.  
Place flywheel/carrier plate on crankshaft so that pin A is 15° below horizontal position, see diagram.


**N.B.** There are two pins. **Do not choose wrong one!**

An etched arrow is also provided on flywheels of later version. The arrow must point straight to right.

Install **new** screws. First coat screw threads with sealing compound (P/N 116 1056-5).

Tighten to **70 Nm** (50 ft lbs). Use toothed sector **5112** as a dolly.

**Automatic transmission:** Note position of base plates. The outer plate must be turned with the edge facing outwards.




J7

**Manual transmission****Install driven plate and pressure plate**

Use centering drift **2484** (early version).

Use centering drift **5111** (late version = plates with involute teeth).

Tighten screws crosswise and a couple of turns at a time, so that no fractures occur.




J8

**Remove toothed sector 5112**


## K. Oil sump, removal

Special tools: 5006, 5033, 5115, 5871




### Drain engine oil

Install plug and a new gasket after draining.  
Tightening torque 60 Nm (43 ft lbs).




### Remove splashguard under engine



### Release main steering shaft steering gear

If steering gear has a protective cover over knuckle, the cover must be pushed up.

Remove lower clamping screw and slacken upper screw. Pull up the carrier on main steering shaft.




Engine without cylinder head

K5

**Lift engine slightly**

Use 2 support bars **5033**, lifting clamp **5006**, lifting hook **5115** and lifting bar **5871**.




Engine with cylinder head

K6

**Lift engine slightly**

Use 2 support bars **5033**, lifting hook **5115** and lifting clamp **5006**.




**Remove left engine mount**

K7

K8


**Remove screws which retain front axle cross member. Pull down cross member**

Remove left and right side screws.



**Remove reinforcing bracket**

K9




K10

### Remove oil sump

Remove all retaining screws for sump.  
Loosen, rotate and pull down sump.  
Remove gasket and clean contact faces.


## Install oil sump



K11

### Fit the oil sump


Place a new gasket on sump.  
Turn lug on gasket towards starter motor support.  
Turn and lift up sump. (Secure it with two screws.)  
Install all the screws. Tightening torque 11 Nm (8 ft lbs).



K12

### Install reinforcing bracket

Tighten bracket retaining screws in stages so that no stresses arise.




114 687

### Install front axle cross member

Push up cross member, install bolts and tighten them.

K13



114 683


### Connect main steering shaft to steering gear

The carrier only fits in one position. Install lower screw and tighten upper screw. Lock with cotter pins.

Tightening torque  $25 \pm 5$  Nm ( $18 \pm 3.5$  ft lbs).

If a protective cover is provided, pull it over the knuckle.

K14



114 685

### Install left engine mount on engine

K15

### Lower engine


Install engine mounts on front axle cross member. Remove lifting tools.

K16

### Install:

- engine mount nuts
- splashguard underneath engine

K17



114 684

### Motor with cylinder head in position

K18


### Fill with engine oil

Oil capacity,<sup>1</sup> excl. oil filter . . . . . 3.35 l (3.5 US qt)  
incl. oil filter . . . . . 3.85 l (4.1 US qt)

<sup>1</sup>Turbo: add 0.6 litre (0.7 US qt) if oil cooler is drained.

## L. Engine mounts

Special tools: 2903, 5006, 5033, 5115




L1

### Removal/fitting

Disconnect battery.

When replacing right engine mount, the oil filter must also be removed.


Use tool **2903**.



L2

### Turbo engine deflection limiter

A deflection limiter is fitted to the right engine support on turbo engines of the late version. If necessary, it may also be fitted on previously built cars. When fitting make sure that it is brought into the correct position. It is guided by a pin on the rubber cushion.



L3

### Lifting tool


The engine mount are relieved with lifting clamp **5006**, two support rails **5033** and lifting hook **5115**.

## M. Engine, replacement


Operations M 1–5

Special tools: 2810, 5035

The engine is lifted out and in, complete with gearbox.



In order to be able to lift out the engine, the coolant and engine oil must first be drained.



### Engine replacement

Use lifting clamp **5035** and lifting eye **2810**.

For parts which must be removed or fitted, see next page.

After lifting in the engine, see page 85.

M1


## Parts which must be removed or installed when replacing engine

### Engine compartment

M2

#### Remove/install

- bonnet (hood)
- battery cable from battery
- air filter
- radiator and fan cover
- turbo engine: exhaust pipe from turbocharger
- loosen and move servo pump and AC compressor to one side
- N.B.** Do not disconnect the hoses
- release electric cables, water hoses, vacuum hoses and wires



M3


### Underneath engine

Jack up car under jack supports.

M4

#### Remove/install

- splashguard under engine
- engine without turbo: exhaust pipe from intake and exhaust manifolds
- engine mount bolts in front axle cross member






### Transmission

M5

#### Remove/install

- front support for exhaust pipe
- (manual transmission) clutch cable and the gear lever
- (automatic transmission): selector linkage from transmission
- speedometer cable
- propeller shaft
- transmission cross member. Support transmission with a jack
- detach electric cables



138 534

## Work to be carried out after lifting in the engine

Operations M6–14



### Manual transmission

M6


#### Adjust reversing lock clamp. Install rubber gaiter

Engage 1st gear.

Adjust clearance between clamp and gear lever. The clearance must be **0.5–1.5 mm** (0.020–0.059 in), measured with a feeler gauge. Tighten fastening screws.

Also check clearance in 2nd gear.

Install rubber gaiter (boot).



### Automatic transmissions

M7

#### Check-adjust gear selector


1. Check that clearance from position D to stop = position 2 to stop.
2. Adjust gear selector rod length if necessary.

**Rough adjustment**, use adjuster at rear of selector rod.

**Fine adjustment**, use sleeve (max. visible thread = 35 mm or 1.4 in).

Extending rod, decreases position D clearance and increases position 2 clearance.

**After adjustment**: Move selector lever to position 1 and the to P. Repeat the check according to 1.



M8

#### Fill with engine oil and coolant

Engine oil volume 3.85 litres (4.1 US qts) (incl. oil filter). On turbo engines, add 0.6 litre (0.6 US qt) for the oil cooler.


The cooling system holds 9.5 litres (10.0 US qts) (manual transmission) and 9.3 litres (9.8 US qts) (automatic transmission). Set heater control to MAX when adding coolant.

### Automatic transmission

M9

#### Check oil level, top up if necessary

The engine must be running and the gear selector must be in position N or P.




128 686

### Carry out an operational check

Start engine and warm it up.

Check for oil and coolant leakage. Top up with coolant if necessary.




128 772

M11

### Adjust throttle cable

The cable must be extended, but must not affect position of control pulley.

At full throttle the pulley must move towards the full throttle stop.



120 773


### Automatic transmission

M12

### Adjust kick-down cable

Press accelerator pedal right down to floor. **N.B.** Do not turn throttle pulley as the adjustment may then be incorrect. In kick-down position, the distance between the adjusting sleeve and cable stop must be:

**BW 35** ..... 43–47 mm (1.694–1.852 in)  
**BW 55 and AW 70/71** .. 50.4–52.6 mm (1.986–2.072 in)




132 607

M13

### Check/adjust:

- timing
- idling speed and CO content.



137 542

### If engine has been dismantled

M14

### Retighten cylinder head bolts

Only screws of early version must be retightened.

1. Warm up engine, then allow to cool for approx. 30 minutes.
2. Slacken bolt approx. 30°. The tighten to **110 Nm** (80 ft lbs).
3. Tighten other bolts in the order given in point 2.

### After approx. 600 miles (1000 km) driving:

- Check/adjust drive belt.
- If modifications have been carried out to the valve system, the valve clearance should be checked/adjusted.


## Removal of parts from engine body

Operations M 15–16

Special tools: 1426, 2520, 5023, 5112

M15



Uncover engine body by removing parts shown in diagram



137 555

M16

Mount engine on support stand 2520 with fixture 5023




## Installing parts in engine body

Operations M 17–21

Special tools: 1425, 5112


Included below are only those steps during which special care should be taken when installing the engine components.



M17

### Use:

- new gaskets and seals
- new screws for flywheel/carrier plate
- new pilot bearing in crankshaft (manual transmission).




138 174

M18

### Check, replace if necessary

- water and vacuum hoses
- clutch, including the throwout (release) bearing.



70 Nm

5112


138 176

M19

### Flywheel (manual) the carrier plate (automatic)

**New screws:** tighten to **70 Nm** (50 ft lbs). Use the toothed sector 5112 as a dolly.

**Automatic transmission:** note position of support plates. The outer plate must be turned with flanged edge facing outwards.



1426


138 175

M20

### Pilot bearing in crankshaft (manual)

Tap in bearing until it contacts crankshaft.  
Use drift **1426**.  
Install locking ring.

M21


**Transmission**

Check that dowels in engine block are in position.

Tighten reinforcing bracket in stages so that no fractures occur.

## Group 22 Lubrication System

	Operations	Page
Engine oil, oil filter .....	N 1-2	90
Oil pressure, checking .....	O 1-3	91
Oil pump, removal/installing .....	P 1-2	92
repair .....	Q 1-7	93




USA, Canada & Japan SAE 15W-40 oil is recommended for use in extreme driving conditions which involve high oil consumption e.g. mountain driving with frequent deceleration or fast motorway driving. Do not, however, use 15W-40 oil at very low temperatures; see chart.

## N. Engine oil, oil filter

Special tool: 2903

N1



### Engine oil

The engine should be hot when changing oil.

Oil capacity<sup>1</sup>, excl. oil filter ..... 3.35 l (3.5 US qts)

incl. oil filter ..... 3.85 l (4.1 US qts)

Difference in volume, max.—min. .... 1.0 l (1.1 US qts)

<sup>1</sup>Turbo engines: Add 0.6 litre (0.7 US qts) for oil cooler if system is completely drained.

### USA, Canada and Japan


#### Oil quality

According to API ..... SF\*

\*Oils with designations SF/CC and SF/CD fulfil this requirement.

Supplementary engine oil additives are not recommended because of potential damage to engine.

#### Viscosity (stable ambient temperatures)



137 644

### Other markets

#### Oil quality

According to API—1983 ..... min. SE\*


1984— ..... SF\*\*

\*Oils with designations SE, SF, SE/CC, SF/CC and SF/CD fulfil this requirement. **Note that SE/CD oils must not be used.**

\*\*Oils with designations SF/CC and SF/CD fulfil this requirement.

Supplementary engine oil additives are not recommended because of potential damage to engine.


#### Viscosity (stable ambient temperatures)



137 642

**USA, Canada & Japan** SAE 15W/40 oils are recommended for use in extreme driving conditions which involve high oil consumption e.g. mountain driving with frequent deceleration or fast motorway driving. Do not, however, use 15W/40 oils at very low temperatures; see chart.

N2

**Oil filter**


Use strap wrench **2903** to remove filter. See instructions on filter. If only the oil filter is changed, add **0.5 l** (0.5 US qt) of engine oil.

## O. Oil pressure, checking

Special tool: 5270

O1

Byt oljerenare

**Check oil pressure**

Connect oil pressure gauge **5270** to adapter at oil pressure transmitter.

On turbo engines, it is easiest to measure oil pressure at recess on rear edge of cylinder head. Use nipple 16218-0 (E).

**N.B.** The measured value will be approx. **10% lower** than if the pressure is measured at transmitter adapter. Coat plug with thread sealant (P/N 1161075-5) before installing.

Oil pressure, with a hot engine, specified oil and new oil filter, at:


33 r/s (2000 rpm) ..... at least **250 kPa** (35.5 psi)

O3

**If oil pressure is not according to specification; check:**

- oil level
- oil leakage
- relief valve in oil pump

## P. Oil pump, removing/installing



128 753

P1

### Removal

Remove oil pump by method described on page 78.

Remove oil pump by removing two screws (arrowed).


P2

### Installing

Use new seals.

Pump is fitted with delivery pipe secured to pump. Align pipe to block so that seal is not damaged.

Tighten two screws.



134 885

1981–

P3


### Secure drain hose from oil trap

Attach clamp for oil trap drain hose to oil pump screw.

Make sure that hose is securely clamped behind oil pump shoulder.




**IMPORTANT!** The hose must have an exact length, it must not be cut.

## Q. Oil pump, overhaul



### Dismantel oil pump

On early version the strainer must be removed to reach cover retaining screws.



### Clean pump

Check gearwheel, housing and cover for wear and damage.


### Test relief valve spring in a spring tester

Load N (lbf)	Length mm (in)
0 (0)	39.2 (1.54)
46-54 (10.35-12.15)	26.25 (1.03)
62-78 (13.95-17.55)	21.0 (0.83)

Q1

Q2

Q3



129 441

#### Check tooth flank clearance

Clearance = 0.15–0.35 mm (0.006–0.014 in).

Q4




129 442

#### Check axial clearance

Clearance = 0.02–0.12 mm (0.001–0.005 in).

Q5




129 444

#### Install piston and spring

Early version has a ball and spring.

Q6



137 553

#### Assemble pump

Connect delivery pipe, use new seals.

Q7

# Index

	Operation	Page		Operation	Page
<b>Camshaft</b>			<b>EGR, stepless</b>		
check axial clearance	F9		A engines 1981-84		18
removal	F1-9	64	E, F engines 1976-77		18-19
installing	F10-16	66	1978-84		19
<b>Camshaft seal, replace</b>	I1-23	71	<b>EGR, on-off</b>		
<b>Carrier plate (automatic transmission)</b>			A engines 1978-81		15
removal	J2	76	1982-84		
installing	J16	77	E, F engines 1976-78		16
<b>Clutch</b>			1981-84		16
removal	G1	68	ET engines 1984-85		17
installing	G5	69	<b>Engine</b>		
<b>Compression test</b>	A1-2	27	lifting out and in	M1	83
<b>Crankshaft pulley</b>			work after lifting in	M6-14	85
removal	E3	61	removal of parts	M15	87
installing	E10	63	installing parts	M17-21	88
<b>Crankshaft seal</b>			<b>Engine oil</b>	N1	90
front	I1-23	71	<b>Engine mount</b>		
rear	J1-8	76	deflection limiter,		
<b>Cylinder bore</b>			turbo engines	L2	82
class marking	D11	57	lifting tool	L3	82
diameter, measurement	D10	56	removal/installing	L1	82
<b>Cylinder head</b>			<b>Evaporation system</b>		
assembly	C45-56	45	A, E, F engines 1975-77		20
checking evenness	C17	38	1978-79		21
cleaning-inspection	C16-44	38	A engines 1980-84		22
dismantling	C10-15	36	E, F engines 1980-84		23
positioning of transmitter			<b>Flywheel</b>		
and contacts	C45	45	removal	J2	76
removal	C1-9	31	installing	J6	77
installing	C57-69	49	<b>Flywheel ring gear</b>		
bolts, different versions	C59	49	replacement	H1-5	70
bolts, retightening	C69	54	<b>Gear box</b>		
bolts, tightening	C59	49	replacing	M21	89
<b>Drive belt</b>			<b>Idling compensation</b>		24
belt tensioning	E9	63	<b>Intermediate shaft seal</b>	I1-23	71
replacement	E1-13	61	<b>Lifting in engine</b>	M1	83
re-adjustment	E13	63	work after lifting in	M6-14	85
tensioner	E6-7	62			

	Operation	Page
<b>Oil filter</b> .....	N2	91
<b>Oil pump</b>		
overhaul .....	Q1-7	93
removal, installing .....	P1	92
<b>Oil sump</b>		
removal .....	K1-10	78
installing .....	K11-18	80
<b>Oil trap</b>		
drain hose .....	P3	92
<b>Pilot bearing in crankshaft</b>		
removal .....	G1-3	68
installing .....	G4	69
<b>Piston rings</b>		
axial clearance, measurement .....	D17	58
replacement .....	D1-27	55
ring gap measurement .....	D18	58
<b>Pistons</b>		
cleaning, inspection .....	D16	58
diameter, measurement .....	D12	57
piston clearance .....	D13	57
removal .....	D7	56
installing .....	D21	59
<b>Pressure plate</b>		
removal .....	G1	68
installing .....	G5	69
<b>Pulley</b>		
camshaft		
removal .....	I6	72
installing .....	I10	73
crankshaft		
removal .....	I12	73
installing .....	I16	74
transmission shaft		
removal .....	I6	72
installing .....	I11	73
<b>Pulsair/Air pump</b> .....		25
<b>Special tools</b> .....		11
<b>Specifications</b> .....		2
<b>Transmission, replacement</b> .....	M21	89
<b>Vacuum hoses (connections)</b> .....		14
<b>Valve adjustment washers</b>		
inspection .....	B5	29
removal .....	B4	29
installing .....	B6	29
<b>Valve cover</b>		
removal .....	B1	28
installing .....	B10	30

	Operation	Page
<b>Valve guides</b>		
replacement .....	C21-25	39
clearance, guide-valve .....	C20	39
seals, removal .....	C15	37
installing .....	C47	46
<b>Valve tappets</b>		
inspection .....	C41	44
removal .....	C13	36
installing .....	C49	47
<b>Valves</b>		
adjustment .....	B1-12	28
grinding .....	C38-40	43
removal .....	C14	37
installing .....	C46	46
scrapping, turbo .....	C19	39
stem .....	C46	46
<b>Valve seats</b>		
replacement .....	C26-37	41
grinding .....	C38-40	43
<b>Valve springs</b>		
different versions .....	C42	44
inspection .....	C42	44
removal .....	C14	37
installing .....	C48	47



VOLVO SUPPORTS VOLUNTARY  
MECHANIC CERTIFICATION  
BY THE N.I.A.S.E.

(U.S.A. only)

*Service literature*

*Your  
most important  
special tool*

# **VOLVO**

TP 30156/2  
6000.11.84  
PRINTED IN U.S.A.