

Service Manual

Section 2 (21)

Reconditioning
engine

B 17, B 19


B 21, B 23

240 1975—1984

Repairs
and maintenance

VOLVO

B 17, B 19, B 21, B 23 engines



B 21 A

137 548

This manual covers the following engine types:

What do the designations mean?

B 21 E T

↓
T = Turbo

↓
A = carburetor engine,
K = carburetor engine
E = fuel injection engine
F = fuel injection engine – USA version

↓
21 = cylinder capacity

↓
B = petrol (gasoline)

Engine type	Model year
B 17 A	1979–1984
B 19 A	1977–1984
B 19 K	1984
B 19 E	1977–1984
B 19 ET	1982–1984
B 21 A	1975–1984
B 21 E	1975–1983
B 21 ET	1981–1984
B 21 F-5 ¹	1976–1984 ³
B 21 F-8 ²	1982
B 21 F-9 ⁴	1981–1982
B 21 FT	1981–1984
B 23 A	1981–1984
B 23 E	1979–1984
B 23 F (LH-Jetronic)	1983–1984

B 21 = basic engine

B 23 = a **B 21** with larger bore and higher compression ratio

B 19 = a **B 21** with smaller bore

B 17 = a **B 19** with shorter stroke

Remarks

¹B 21 F-5 = CI system with Bosch ignition system.

²B 21 F-8 = LH Jetronic injection system.

³Discontinued 1982 in USA & Canada.

Superseded by B 21 F-8.

⁴B 21 F-9 = CI system with Chrysler ignition.

Volvos are sold in versions adapted for different markets. These adaptations depend on many factors including legal, taxation and market requirements.

This manual may therefore show illustrations and text which do not apply to cars in your country.

Contents

	Page
Important information	2
Specifications	2
Special tools	10
Operation	
Thread repairs	A 1-14 12
Reconditioning engine	18
Disassembly	B 1-13 19
Cleaning and inspection	C 1-33 23
Assembly	D 1-27 32
Cylinder head, reconditioning	E 1-54 39
Assembly (cont)	F 1-9 54

Index page 57


This manual deals exclusively with the overhaul of the engine.
For work carried out on the engine when fitted in the car, and for engine removal and installation, please refer to the separate manuals.

Order number: TP 30170/2
Supersedes: TP 30170/1

We reserve the right to make alterations without prior notification.

B17, B19, B21, B23 engines

Important information



135 020


Tightening torques

Two types of tightening torques are used in this Manual:

- I. Tightening torque **40 Nm** (30 ft.lbs) = a torque wrench must be used.
- II. Tightening torque **40 Nm** (30 ft.lbs) = correct value, however it is not necessary to use a torque wrench.

Specifications

Group 20 General



114 651


Engine type designation, serial number and part number

Stamped on a plate on left side of engine.
1977-models: additional plate on timing gear cover showing last three digits of part number.

Group 21 Engine assembly

CYLINDER HEAD

Height	New 146.1 mm (5.7563 in)
Min height after machining	145.6 mm (5.7366 in)







129 827

Max distortion

Note that if distortion is greater than 1.0 mm (0.040 in) lengthwise and 0.5 mm (0.020 in) crosswise the cylinder head must not be machined but replaced.

Thickness of gasket

new 1.3 mm (0.051 in)
fitted 1.2 mm (0.047 in)



CYLINDER BLOCK

Bore

		B 17, B 19	B 21	B 23
Standard (marked C)	mm	88.90–88.91	92.00–92.01	96.00–96.01
	(in)	(3.5027–3.5031)	(3.6248–3.6252)	(3.7824–3.7828)
(marked D)	mm	88.91–88.92	92.01–92.02	96.01–96.02
	(in)	(3.5031–3.5034)	(3.6252–3.6256)	(3.7828–3.7832)
(marked E)	mm	88.92–88.93	92.02–92.03	96.02–96.03
	(in)	(3.5034–3.5038)	(3.6256–3.6260)	(3.7832–3.7836)
(marked G)	mm	88.94–88.95	92.04–92.05	96.04–96.05
	(in)	(3.5042–3.5047)	(3.6264–3.6268)	(3.7840–3.7844)
Oversize 1	mm	89.29–89.30	92.5	96.3
	(in)	(3.5180–3.5184)	(3.6445)	(3.7942)
2	mm	89.67–89.68	93.0	96.6
	(in)	(3.5330–3.5334)	(3.6642)	(3.8060)

Rebore if wear exceeds 0.1 mm (0.004 in) and oil consumption is very high.


Pistons

A = Overall height

B = From gudgeon (piston) pin center to crown

C = Diameter to be measured at right angles to gudgeon pin at distance "C" from bottom of piston

Engine type	Weight gms ¹ (oz)	Dimension mm (in)		
		A	B	C
B 17 A	530±6 (18.9±0.2)	75.5 (2.975)	50.5 (1.990)	7 (0.276)
B 19 A	505±6 (18.0±0.2)	71.0 (2.797)	46.0 (1.812)	7 (0.276)
B 19 E-1983	515±6 (18.4±0.2)	71.0 (2.797)	46.0 (1.812)	7 (0.276)
1984	515±6 (18.4±0.2)	73.9 (2.912)	46.7 (1.840)	7 (0.276)
B 19 ET	510±6 (18.2±0.2)	71.0 (2.797)	46.0 (1.812)	7 (0.276)
B 19 K	515±6 (18.4±0.2)	73.9 (2.912)	46.7 (1.840)	7 (0.276)
B 21 A ²	555±6 (19.8±0.2)	71.0 (2.797)	46.0 (1.812)	6 (0.236)
B 21 E	555±6 (19.8±0.2)	71.0 (2.797)	46.0 (1.812)	6 (0.236)
B 21 ET	535±6 (19.1±0.2)	71.5 (2.817)	46.5 (1.832)	7 (0.276)
B 21 F	555±6 (19.8±0.2)	71.5 (2.817)	46.5 (1.832)	7 (0.276)
B 21 FT	535±6 (19.1±0.2)	71.5 (2.817)	46.5 (1.832)	7 (0.276)
B 23 A	570±7 (20.4±0.3)	76.4 (3.010)	46.4 (1.828)	8 (0.315)
B 23 E type 1	555±6 (19.8±0.2)	80.4 (3.168)	46.4 (1.828)	15 (0.591)
type 2	570±7 (20.4±0.3)	76.4 (3.010)	46.4 (1.828)	8 (0.315)
B 23 F ³	570±7 (20.4±0.3)	76.4 (3.010)	46.4 (1.828)	8 (0.315)



137 551



¹ Max weight difference in same engine = 12 gms (0.43 oz)

² Europe 1984- (excl Switzerland, Scandinavia) models have high compression pistons, A=71.7 mm (2.82 in); B=46.7 mm (1.84 in); C=7 mm (0.28 in)

³ Pistons dished on engine numbers 499846, 499890

Piston running clearance mm (in)

B 17 A, B 19 A/E/K, B 21 A/E/F	0.01–0.04 (0.0004–0.0016)
B 19 ET	0.03–0.06 (0.0012–0.0024)
B 21 ET & FT	0.02–0.04 (0.0008–0.0016)
B 23 A	0.01–0.04 (0.0004–0.0016)
B 23 E type 1	0.05–0.07 (0.0020–0.0028)
type 2	0.01–0.04 (0.0004–0.0016)
B 23 F	0.01–0.04 (0.0004–0.0016)

Piston rings

Measure gap
15 mm (0.59 in) from
lower edge


	mm	mm	mm
Piston height, type 1	1.978–1.990	1.978–1.990	4.74
	(0.0779–0.0783)	(0.0779–0.0783)	(0.1866)
type 2	1.728–1.740	1.978–1.990	3.978–3.990
	(0.0681–0.0685)	(0.0779–0.0783)	(0.1566–0.1571)
Clearance in piston groove	0.040–0.072	0.040–0.072	0.030–0.062
	(0.0016–0.0028)	(0.0016–0.0028)	(0.0012–0.0024)
Ring gap (see above fig)	0.35–0.65	0.35–0.55	0.25–0.60
	(in)	(0.014–0.022)	(0.010–0.024)

Gudgeon (piston) pins




Fit, in connecting rod	Light thumb pressure (close running fit)
in piston	Thumb pressure (push fit)
Diameter, standard	mm (in) 24.00 (0.945)
oversize	mm (in) 24.05 (0.947)

VALVES**Valve clearance**

Inlet and exhaust valves		
cold engine	0.30–0.40 mm	0.35–0.40 mm
	(0.012–0.016 in)	(0.014–0.016 in)
warm engine	0.35–0.45 mm	0.40–0.45 mm
	(0.014–0.018 in)	(0.016–0.018 in)
Adjusting shims, thickness	3.30–4.50 mm (0.1300–0.1773 in) in increments of 0.05 mm (0.002 in)	

Valves mm (in)

Inlet valve

Exhaust valve
A, E, F-enginesExhaust valve
Turbo-engines**Valve seats**



Inlet valve seat

Exhaust valve seat

Turbo: exhaust valves are Stellite-coated and must not be machined to obtain new surface. They can however be ground-in with paste against seat.

Valve seat diameter		Inlet	Exhaust
standard	mm	46.00	38.00
	(in)	(1.8124)	(1.4972)
oversize 1	mm	46.25	38.25
	(in)	(1.8223)	(1.5071)
2	mm	46.50	38.50
	(in)	(1.8321)	(1.5169)

$D + 0.17 \text{ mm (0.0067 in)}$




113 945

When replacing valve seats the interference between the seat and its bore should be 0.17 mm (0.0067 in) i.e. valve seat diameter should be 0.17 mm (0.0067 in) greater than diameter of bore in cylinder head.

Valve guides mm (in)

		Inlet valve	Exhaust valve
Length	mm	52	52
	(in)	(2.0488)	(2.0488)
Inner diameter	mm	8.000–8.022	8.000–8.022
	(in)	(0.3152–0.3161)	(0.3152–0.3161)
Height above upper face of cylinder head	mm	15.4–15.6	17.9–18.1
	(in)	(0.6068–0.6146)	(0.7053–0.7131)
Clearance, valve stem – guide (measured with new valve)			
new	mm	0.030–0.060	0.060–0.090
	(in)	(0.0012–0.0021)	(0.0024–0.0035)
max.	mm	0.15	0.15
	(in)	(0.0059)	(0.0059)




113 946

Valve guides are available in three oversizes, marked with grooves.


	Marking	Reamer for seat
Standard	No groove	—
Oversize 1	1 groove	5161
2	2 groove	5162
3	3 groove	5163

Note. The force used when pressing in valve guides must be at least **9000 N (900 kp)**. If the pressing force used is lower, then the recess for the guide must be reamed out to the nearest oversize and a guide of the corresponding size pressed in.


Valve springs mm (in)



Type 1



Type 2



115 083

Type 2 springs are fitted on following engine types:

- B 21 F LH-Jetronic, late types (from 1983–)
- B 23 F
- B 19 ET, B 21 ET & B 21 FT late type (from 1984–).

Type 1 springs are fitted on all other engines types.

Type 1		Type 2	
Length	Load N (lb)	Length	Load N (lb)
45.0 (1.77)	0	45.5 (1.79)	0
38.0 (1.50)	280–320	3.80 (1.50)	280–320
	(62–70)		(62–70)
27.0 (1.06)	710–790	27.5 (1.08)	702–782
	(156–174)		(154–172)

Tappets mm (in)

Diameter	36.975–36.995 (1.4568–1.4576)
Height	30–31 (1.182–1.221)
Clearance, adjusting shim to cylinder head	0.009–0.064 (0.0004–0.0025)
adjusting shim to tappet	0.030–0.075 (0.0012–0.0030)


Adjusting shims mm (in)

Thickness	3.30–4.50 (in increments of 0.05)
	(0.1300–0.1773) (in increments of 0.0020)
Diameter	32.980–33.0 (1.2994–1.3002)

TIMING GEARS**Camshaft mm (in)**

Engine type	Profile
B 17 A, B 19 A	A
B 19 K	L
B 19 E 1977–1983	D
1984	A
B 19 ET	T
B 21 A 1975–1983	A
1984 CH, Scandinavia Australia, Other markets	A
B 21 E	L
B 21 ET	D
B 21 F-5	T
B 21 F-8	B
B 21 F-9	M
B 21 FT	L
B 23 A	T
B 23 E 1979–1980	A
1981–1982	H
1983 Canada	K
Other markets	A
1984	K
B 23 F	A
	M

Camshaft max lift height mm (in)	Check values (cold engine)	
	Valve clearance No. 1 intake valve	Intake valve should open at:
A/10.5 ¹ (0.4137)	0.7 (0.0276)	13° B.T.D.C. ¹⁾
B/10.6 (0.4176)	0.7 (0.0276)	19° B.T.D.C.
D/11.2 (0.4413)	0.7 (0.0276)	15° B.T.D.C.
H/12.0 (0.4728)	0.5 (0.0197)	28° B.T.D.C.
K/11.95 (0.4708)	0.5 (0.0197)	22.6° B.T.D.C.
L/9.8 (0.3861)	0.7 (0.0276)	10° B.T.D.C.
M/9.5 inlet	0.7 (0.0276)	3° A.T.D.C.
10.5 exhaust	0.7 (0.0276)	48° B.T.D.C.
T/9.9 (0.3901)	0.5 (0.0197)	11° B.T.D.C.

¹1975 early types: 9.8 mm, 5° B.T.D.C.

133 662

Bearing journal, diameter	29.050–29.070 (1.1445–1.1454)
Radial clearance, new	0.030–0.071 (0.0012–0.0028)
max.	0.15 (0.0059)
Axial clearance	0.1–0.4 (0.0344–0.0158)

Camshaft bearings mm (in)

Bearing diameter	30.000–30.021 (1.1820–1.1828)
------------------------	-------------------------------

Intermediate shaft mm (in)

	Bearing journal	Bearing in cylinder
Diameter, front	46.975–47.000 (1.8508–1.8518)	47.020–47.050 (1.8526–1.8538)
center	43.025–43.050 (1.6952–1.6962)	43.070–43.100 1.6970–1.6981)
rear	42.925–42.950 (1.6912–1.6922)	42.970–43.000 (1.6930–1.6942)
Radial clearance	0.020–0.075 (0.0008–0.0030)	
Axial clearance	0.20–0.46 (0.0079–0.0181)	


CRANKSHAFT ASSEMBLY

Crankshaft mm (in)

Max. out-of-true	0.05 (0.0020)
Crankshaft, axial clearance, max.	0.25 (0.0098)
radial clearance (main bearings)	0.028–0.083 (0.0011–0.0033)
Big-end bearings, axial clearance	0.15–0.35 (0.0059–0.0138)
radial clearance	0.024–0.070 (0.0009–0.0028)

Main bearing journals mm (in)

Out-of-round, max.	0.07 (0.0028)
Taper, max.	0.05 (0.0020)
Diameter, standard	63.451–63.464 (2.5000–2.5005)
undersize 1	63.197–63.210 (2.4900–2.4905)
2	62.943–62.956 (2.4800–2.4805)
Width on crankshaft for flange bearing shell,	
standard	38.960–39.000 (1.5350–1.5366)
oversize 1	39.061–39.101 (1.5390–1.5406)
2	39.163–39.203 (1.5430–1.5446)



Connecting rod bearing journals mm (in)

Out-of-round max.	0.05 (0.0020)
Taper, max.	0.05 (0.0020)
Diameter, standard	53.987–54.000 (2.1271–2.1276)
undersize 1	53.733–53.746 (2.1171–2.1176)
2	53.479–53.492 (2.1071–2.1076)
Bearing recess width	29.95–30.05 (1.1800–1.1840)

Connecting rods mm (in)


Axial clearance at crankshaft	0.15–0.35 (0.0059–0.0138)
Length, centre–centre	145±0.1 (5.713±0.0039)
Max. weight deviation between connecting rods in same engine	10 gms

Flywheel mm (in)

Axial throw, max	0.05 mm/150 mm diameter (0.0020 in/5.91 in diameter)
------------------------	---


The tightening torques apply to oiled screws, bolts and nuts. Degreased (washed) parts must be oiled before use.

Cylinder head, tightening sequence data



Early type

- 1 = **60 Nm** (43 ft.lbs)
- 2 = **110 Nm** (80 ft.lbs)
- 3 = Run warm. Then allow engine to cool off for about 30 minutes.
- 4 = Slacken bolt 1 approx. 30°. Then tighten to a torque of **110 Nm** (80 ft.lbs) (The bolt must be slackened first to break the resting stress, otherwise false tightening torque will result.
- 5 = Tighten other bolts in sequence, see step 4.




Late type

- 1 = 20 Nm (14 ft.lbs)
2 = 60 Nm (43 ft.lbs)
3 = Angle-tighten 90°

Bolts should be replaced if center section shows signs of extension. Do not re-use bolts more than 5 times.

If in doubt, fit new bolts.



Tightening sequence for cylinder head bolts

	Nm	(ft.lbs)
Main bearings	110	80
Connecting rod bearings, old bolts	63	46
new bolts	70	51
Flywheel (use new bolts)	70	51
Spark plugs (not to be oiled)	20–30	14–22
Camshaft gear	50	36
Intermediate shaft gear	50	36
Camshaft cap	20	14
Crankshaft, centre bolt pulley	165	119

Group 22 Lubricating system

Oil capacity, excl oil filter	3.35 l (3.5 US qt)
incl oil filter	3.85 l (4.0 US qt)
Max-Min	1.0 l (1.1 US qt)

Turbo-engines: add 0.6 l (0.7 US qt) to above if oil cooler is drained.

Oil pressure at 33 r/s (2000 r/min), warm engine and new oil filter	0.25–0.60 MPa 35.6–85.3 psi
---	--------------------------------

USA, Canada and Japan

According to API..... min SF*

According to API – 1983..... min SE*
1984..... min SF**

****oils with designations SF/CC and SF/CD meet this requirement.**

137 644


137 642

115 083


0
46-54 N (10.1-11.9 lb.)
62-78 N (13.6-17.2 lb.)

Special tools


999	Description – use
1426-6	Drift: installing pilot bearing
2484-7	Centering drift: installing clutch plate (early gearbox types)
2520-8	Stand: Used with fixture 5023
4090-0	Extractor: pilot bearing
5017-2	Drift: installing/removing connecting rod bushing
5021-4	Press tool: installing/removing camshaft
5022-2	Press tool: adjusting valves
5023-0	Fixture: used with stand 2520
5024-8	Sleeve: installing crankshaft front seal
5025-5	Sleeve: installing camshaft and intermediate shaft seals
5026-3	Pliers: removing valve tappets
5027-1	Drift: installing intake valve guides
5028-9	Drift: installing exhaust valve guides
5029-7	Drift: installing intake valve seats
5034-7	Counterhold: crankshaft, intermediate shaft, camshaft
5111-3	Centering drift: clutch (late gearbox types)
5112-1	Gear sector: locking flywheel
5160-0	Reamer kit: contains 5161, 5162, 5163, 5164 (early type) or 5224 (late type)
5161-8	Reamer: for valve guide OS1
5162-6	Reamer: for valve guide OS2
5163-4	Reamer: for valve guide OS3
5218-6	Drift: removing valve guide
5219-4	Tool: removing/installing valve guide seals
5220-2	Drift: for checking valve
5222-8	Gauge: for checking valve stem length
5224-4	Reamer: inside (replaces 5164)
5276-4	Press tool: installing crankshaft rear seal




1426




2484




2520




4090




5017




5021




5022




5023




5024, 5025




5026




5027, 5028




5029




5034




5111




5112




5160, 5161, 5162, 5163




5218




5219




5220



5222





5224



5276

A. Thread repairs



A1

General


Damaged threads can usually be repaired with thread inserts. Thread inserts and installation tool are available from Volvo Parts.

Note. Some threads can/may not be repaired with thread inserts (refer to the illustration and table for the part concerned)

A2

Installation tool

Complete set or separate parts can be ordered from Volvo Parts.



Thread	Complete Kit, No.	Supplied with kit					
		A. Tap	B. Tang breaker	C. Mandrel	D. Crank	E. Tool	Thread inserts 10
M 6×1	998 5840-9	998 5802-9	998 5803-7	998 5804-5	998 5805-2	4)	956014-5 + 956015-2
M 7×1	998 5841-7	998 5806-0	998 5807-8	998 5808-6	998 5809-4	4)	948015-3 + 941843-5
M 8×1,25	998 5842-5	998 5810-2	998 5811-0	998 5812-8	998 5813-6	4)	956018-6 + 956019-4
M 10×1,5	998 5843-3	998 5814-4	998 5815-1	998 5816-9	998 5817-7	4)	956022-8 + 956023-6
M 12×1,5	998 5844-1	998 5818-5	998 5819-3	998 5820-1	998 5821-9	4)	948094-8 + 948095-5
M 14×1,25	998 5845-8 ¹⁾	998 5823-5	2)	998 5824-3	998 5825-0	4)	948756-2
M 14×1,25	998 5846-6	998 5826-8	2)	998 5824-3	998 5825-0	4)	948756-2
M 14×1,5	998 5847-4	998 5827-6	2)	998 5828-4	998 5829-2	4)	948758-8
M 16×1,5	998 5848-2	998 5831-8	2)	3)	3)	998 5832-6	947847-0
M 18×1,5	998 5849-0	998 5833-4	2)	3)	3)	998 5834-2	947843-9
5/8"– 18 UNF	998 5850-8	998 5860-7	2)	3)	3)	998 5861-5	948755-4

¹⁾Intended for spark plug threads (no drilling)



²⁾Use flat-nosed pliers or similar tool

³⁾Supplied with installation tool

⁴⁾Tool 998 5830-0 is not supplied with complete kit and should be ordered separately if required.

Do not repair these threads
(Threads shown below cannot or must not be repaired)

A3


Cylinder head**Inlet manifold**

137 807

All conical threads such as plugs and nipples in inlet manifold on all engine types. A few examples are shown above.

Later type inlet manifolds have a few unthreaded holes intended for self-tapping screws.


Inlet manifold A-engines




137 808

Thread repair insert, drill diameter

A4



Thread	Length mm	P/N	Drill dia mm
M 6×1	9.0	956014-5	6.3
	12.0	956015-2	6.3
M 7×1	10.5	948015-3	7.3
	14.0	941843-5	7.3
M 8×1.25	8.0	956017-8	8.4
	11.4	956018-6	8.4
	16.0	956019-4	8.4
M 10×1.5	10.0	956021-0	10.5
	15.0	956022-8	10.5
	20.0	956023-6	10.5
	25.0	956024-4	10.5
M 12×1.5	12.0	948094-8	12.5
	24.0	948095-5	12.5
	30.0	956028-5	12.5
M 14×1.25	14.5	948756-2	14.3
M 14×1.5	10.0	948758-8	14.5
M 16×1.5	12.0	947847-0	16.5
M 18×1.5	13.5	947843-9	18.5
5/8"×18UNF	8.0	948755-4	16.4



Combination tap

Tap section

Reamer section

Guide

A5

Repairing spark plug threads


Cylinder head must be removed first. Tap hole from inside to avoid damaging seat for spark plug.

Do not drill the hole. Use tap 998 5823-5.

Re-cut old threads only. Do not cut further into cylinder block. Spark plug bore must not be threaded along entire length.

Screw in thread insert (P/N 948756-2).


Installing thread inserts



A6

Select drill size, tap and insert

Measure length and thread of old hole.



A7


Tap hole

NOTE! Special instructions for spark plug holes, see page 14.

Measure depth of hole. Drill out hole to this depth.

Cut the screw thread to such a depth that the thread insert makes contact with fully cut screw thread along its entire length.

Clean the hole.




A8

Assemble installation tool

M6–M14 threads: fit correct mandrel and crank in installation tool 998 5830-0.

M16 and coarser threads: use the appropriate installation tool.



113 299


A9

Fit thread insert in installation tool

Fit the thread insert in the tool with the tang facing downwards.

Turn the crank clockwise until the tang of the thread insert engages the slot in the crank.

Without pressing, screw the thread insert into the mandrel until the first thread of the insert is flush with the opening of the mandrel.




113 300

A10

Install thread insert

Hold the tool vertically above the centre of the hole.

Without pressing, screw in the thread insert until the top thread of the insert is at least $\frac{1}{2}$ a thread below the working surface ($0.5 \times \text{pitch}$). The insert must not be screwed in to the bottom otherwise it will not be possible to break off the tang.



113 301

A11


Break off tang

M16–M12 threads: use the tang breaker supplied with the installation kit.

M14 and coarser threads: use a pair of flat nosed pliers to break off the tang downwards.

Remove the tang from the hole.


Removing thread repairs inserts



A12

File groove in thread insert


Using a triangular file make a groove in the top thread of the insert, approx. 1/4 of a thread from the end. Take care not to damage the thread holding the insert.



A13

Remove thread insert

Insert a sharp edge of a triangular scraper in the groove. Press downwards and rotate anti-clockwise until the insert is removed.




A14

Fit new thread insert

Clean the hole with a tap and fit a new insert.

B. Engine, disassembly



TIMING GEARS AND CYLINDER HEAD

B1


Remove timing gear case, crankshaft pulley and drive belt

Slacken belt as follows:

- slacken nut for drive belt tensioner
- stretch belt by hand
- retighten nut

Important

To prevent damage, do not rotate crankshaft or camshaft when gear belt is removed as pistons may strike valves.




B2

Remove rocker cover and cylinder head

Unscrew screws in sequence shown adjacent.

Important


Cylinder head is made of aluminum. To avoid damage it should be placed on wooden supports when removed.



B3

Remove:


- water pump
- pipe to heater



B4

Remove pulley from intermediate shaft


Use **5034** to lock shaft.



B5

Remove:


- crankshaft centre bolt use counterhold **5034**
- hub, guide plates and pulley
- key in crankshaft (only early types).



B6

Remove:


- rear belt guard
- oil seals from flange. Pry out with a screwdriver
- front sealing flange
- spacer sleeve from crankshaft (only early types).




B7

Remove:


- (–1980) oil pump cover and pinion
- (1981–1984) oil trap and pinion
- intermediate shaft

**FLYWHEEL, OIL SUMP, OIL PUMP****Manual gearboxes****B8****Remove:**


- pressure plate and driven plate. Slacken pressure plate bolts crosswise, a few turns at a time to prevent warp
- flywheel. Use locking sector **5112** to prevent crankshaft from rotating
- lockring
- pilot bearing from crankshaft. Use puller **4090**

**Automatic gearboxes****B9****Remove:**


- carrier plate with support plate and coupling flange. Use locking sector **5112** to lock flywheel when removing bolts.
- guide sleeve

**B10****Remove:**

- crankshaft rear oil seal. Pry seal out with a screwdriver. Check if seal is flush with flange or 3 mm (0.1 in) from flange, so that it can be refitted in same position.

**Remove:**

- support bracket
- oil sump
- rear sealing flange
- oil pump and delivery pipe



Pistons, connecting rods


An easy way to rotate crankshaft while disassembling engine, is to place two screwdrivers in flywheel mount.

B11

Check connecting rod side clearance

Using a feeler gauge. Check that clearance = **0.15–0.35 mm** (0.0059–0.0137 in).

If side play is too large, replace connecting rods.




B12

Remove pistons and connecting rods

Rub down any wear ridges in cylinder.

Check identification marks on connecting rod cap, mark if necessary.

Assemble connecting rod, bearing and cap shells to prevent interchange of parts.



Crankshaft


B13

Remove crankshaft and main bearings

Check identification marks on caps, mark if necessary.

Important Do not interchange bearing shells and caps.

C. Cleaning, checking




130 344

Clean:


- cylinder bores (polish dull parts)
- cylinder block (contact faces, bearing seats, oilways, holes for cylinder head bolts, remove old gasket material)
- crankshaft, blow compressed air through oilways
- main bearing caps and shells.

C1



Taper

Out-of-round 129 452



137 788

Examine crankshaft

Measure out-of-round and taper with micrometer. Take measurements at different points on journals.

Connecting rod journals

Max out-of-round **0.05 mm** (0.0020 in)
Max taper **0.05 mm** (0.0020 in)

Main bearing journals

Max out-of-round **0.07 mm** (0.0028 in)
Max taper **0.05 mm** (0.0020 in)


Journals can be ground down to two undersizes, see specifications on page 7.

If crankshaft is thought to be out-of-true, check with a dial indicator as follows.


Support crankshaft on 'V' blocks. Rotate one turn and measure out-of-true for two centre journals.

Out-of-true = **max 0.05 mm** (0.0020 in)


C2




119 684



130 346



131 206



131 370

Measure cylinder bores

Use an accurate bore gauge (range = 50–100 mm or 2–4 in).

Measure **max wear** crosswise just below top dead centre.
Measure **min wear** lengthwise at bottom dead centre.

C4

Identification

A letter is stamped into block next to each cylinder. (C, D, E or G).

Oversizes are indicated by OD1 (OS1) or OD2 (OS2): After reboring, punch in new size (mark).

Standard	B 17, B 19	B 21	B 23
(C-marked)			
mm	88.90-88.91	92.00-92.01	96.00-96.01
(in)	(3.500-3.5004)	(3.6220-3.6224)	(3.7795-3.7799)
(D-marked)			
mm	88.91-88.92	92.01-92.02	96.01-96.02
(in)	(3.5004-3.5008)	(3.6224-3.6228)	(3.7799-3.7803)
(E-marked)			
mm	88.92-88.93	92.02-92.03	96.02-96.03
(in)	(3.5008-3.5012)	(3.6228-3.6232)	(3.7803-3.7807)
(G-marked)			
mm	88.94-88.95	92.04-92.05	96.04-96.05
(in)	(3.5016-3.5019)	(3.6236-3.6240)	(3.7811-3.7815)
Oversizes:			
OS1 mm	89.29-89.30	92.5	96.3
(in)	(3.5153-3.5157)	(3.64)	(3.79)
OS2 mm	89.67-89.68	93.0	96.6
(in)	(3.5303-3.5307)	(3.66)	(3.80)

C5

Measure piston diameter

Measure diameter at right angles to gudgeon (piston) pin.
Diameter must be measured at different points depending on piston/engine type.

- B 21 A/E = **6 mm** (0.24 in) from bottom edge of skirt
- B 23 type 1 (piston size 80.4 mm or 3.17 in) = **15 mm** (0.59 in) from bottom edge
- B 23 type 2 (A, E, and F) (piston size 76.4 mm or 3.01 in) = **8 mm** (0.31 in) from bottom edge
- Others = **7 mm** (0.28 in) from bottom edge

C6


Calculate piston clearance in cylinder

Example:


Measure bore	min 92.02 mm (3.6228 in)	max 92.03 mm (3.6232 in)
Measure piston diameter	92.00 mm (3.6220 in)	92.00 mm (3.6220 in)
Clearance	0.02 mm to (0.0008 in)	0.03 mm (0.0012 in)

Piston clearance:

B 17 A, B 19 A/E/K, B 21 A/E/F	0.01–0.04 mm (0.0004–0.0016 in)
B 19 ET	0.03–0.06 mm (0.0012–0.0023 in)
B 21 ET & FT	0.02–0.04 mm (0.0008–0.0016 in)
B 23 A	0.01–0.04 mm (0.0004–0.0016 in)
B 23 E	
type 1 (piston size 80.4 mm 3.17 in)	0.05–0.07 mm (0.0019–0.0028 in)
type 2 (piston size 76.4 mm 3.01 in)	0.01–0.04 mm (0.0004–0.0016 in)
B 23 F	0.01–0.04 mm (0.0004–0.0016 in)



137 787



130 345

C7

Remove rings from pistons

Use piston ring pliers.

C8

Disassemble connecting rods from pistons

Check that pistons and connecting rods are marked prior to dismantling.

C9

Clean and inspect pistons

Remove all traces of carbon. Scrape out grooves with e.g. an old, ground piston ring.

Check for:

- damage
- signs of wear
- cracks




119 688

C10


Check ring to groove clearance

Use a feeler gauge


Upper compression ring	0.040–0.072 mm (0.0016–0.0028 in)
Lower compression	0.040–0.072 mm (0.0016–0.0028 in)
Oil scraper ring	0.030–0.062 mm (0.0012–0.0024 in)



129 520



130 347



119 692



119 689

C11

Check piston ring gap

Insert piston ring in bore (use an inverted piston to ensure that ring takes up correct position.)

Measure gap 15 mm (0.6 in) from lower edge, using a feeler gauge.

Upper compression ring	0.35–0.65 mm (0.014–0.026 in)
Lower compression ring	0.35–0.55 mm (0.014–0.022 in)
Oil scraper ring	0.25–0.60 mm (0.010–0.024 in)

C12

Clean and inspect connecting rods

Check for:

- damage
- signs of wear
- cracks
- damaged threads

C13

Check gudgeon (pistons) pin fit


It should be possible to slide pin through bore with light thumb pressure.

C14

Check gudgeon (piston) pin fit in piston

Pin must not be loose. It should be possible to press pin through with thumb pressure.

Oversized pins can be used if bore is worn.



130 113

Replacing damaged connecting rod bolt


Operation C15–16

C15

Tap out old bolt

Remove cap and shells.

Rest connecting rod on hard, level surface and tap bolt out with a mallet.




130 114

Install new bolts

Position cap, observing assembly marks.

Place a 12 mm socket beneath cap and press in new bolt.

C16



119 690


Replacing connecting rod bushing

Operations C17–19

C17

Press out old bushing

Use small end of drill 5017.




119 691

Press in new bushing

Use wide end of 5017.

C18

Important Make sure that lubrication holes in bushing and connecting rod align




119 692

C19

Check gudgeon (piston) pin fit in new bushing

It should be possible to slide pin through bore with light thumb pressure without any noticeable looseness.

If necessary, machine bushing.




116 220

C20

Check connecting rod

Use an alignment gauge to check for out-of-true twist, S-form.



135 725

C21

Clean and inspect flywheel (manual gearbox) and carrier plate (auto)

If replacement is necessary, carrier plate must be replaced along with ring gear.

Damaged worn flywheel must be replaced with ring gear attached but ring gear can be replaced separately.

New flywheels are rustproofed and should be degreased prior to assembly

Two different types of flywheels are in use on manual gearbox vehicles.

Replacing ring gear


Operations C22–26

C22

Heat new ring gear to 230°C (450°F)

Heat ring gear in an oven or with an oxyacetylene torch.

If oven is to be used, begin heating at this stage.



129.451


C23

Drill a hole between two cogs.

Use an 10 mm (0.4 in) drill.

Depth = 9 mm (0.35 in).

Important: Do not drill into flywheel as this may cause out-of-balance.



129.450


C24

Remove ring gear

Mount flywheel in a vice protected by soft jaws.

Lever off ring gear with a screwdriver. It may be necessary to split ring gear above drilled hole.

Clean mating surfaces on flywheel.



129.449

C25

Heat new ring gear to 230°C (450°F)

Check temperature with solder (40% tin, 60% lead) solder melts at 220–230°C (430–450°F).


C26

Install new ring gear

Important: Bevelled side of ring gear must face flywheel.

If necessary tap ring gear until flush with flywheel, using a brass drift.

Leave to cool.




Oil pump, cleaning – inspection
Operations C27–33

C27

Disassemble oil pump


On older types it is necessary to remove strainer to obtain access to retaining screws.



C28

Clean and inspect pump

Check gears, pump body and cover for signs of wear and damage.



C29


Test relief valve spring

Load	Length
0	39.2 mm (1.5445 in)
46–54 N (10.1–11.9 lb.)	26.25 mm (1.0343 in)
62–78 N (13.6–17.2 lb.)	21.0 mm (0.8274 in)

C30

Check backlash

0.15–0.35 mm (0.0059–0.0138 in).






129 442

Check gear end play

0.02–0.12 mm (0.0008–0.0047 in).

C31




129 444

Fit plunger and spring

Earlier types have a valve ball and spring.

C32



Late type

Early type

Assemble oil pump

Connect delivery pipe using new oil seals.

C33