


# B 6244, B 6254, B6304



## Definitions

B 6 3 0 4 F S

S = Normally aspirated engine

F = Injection engine with catalyzer

G = Injection engine without catalyzer

4 = Valves per cylinder

3 0 = Cylinder capacity

6 = No. of cylinders

B = Petrol

## This manual covers the following engines:

Engine model	Year
B 6244	1995–
B 6254	1995–
B 6304	1991–

### Modifications to March 1994 included

Modifications introduced after the above date are not covered in this manual.  
See Service Bulletins as applicable.

Volvos are sold in versions adapted for different markets. These adaptations depend on many factors including legal, taxation and market requirements. This manual may therefore show illustrations and text which do not apply to cars in your country.

Volvo owners planning to export their car(s) to another country should investigate the applicable safety and exhaust emission requirements. In some cases it may be impossible to comply with these requirements.

# Contents

<b>Important</b> .....	2
<b>Specifications</b> .....	4
<b>Universal tools</b> .....	12
<b>Special tools</b> .....	13

## Reconditioning engine

### Dismantling engine, cleaning, inspection

	<b>Step</b>	<b>Page</b>
Cylinder head, exposure .....	A1–A6	18
Timing belt and drive assembly, dismantling .....	B1–B15	21
Cylinder head, removal .....	C1–C5	25
Crank mechanism, dismantling .....	D1–D7	27

### Measurement, reconditioning

Cylinder block, measurement .....	E1–E3	29
Crank mechanism, measurement .....	F1–F17	30
Cylinder head, measurement/reconditioning .....	G1–G20	35
Threads, repair .....	H1–H7	41
Hermetically sealed bolts, sealing .....	I1–I5	50

### Reassembly

Crank mechanism, reassembly .....	J1–J12	54
Cylinder head, installation .....	K1–K7	58
Timing belt assembly, reassembly .....	L1–L10	60
Cylinder block, refitting components .....	M1–M6	63


**Index page 66**

This service manual covers engine reconditioning only. For work on engine in car and lifting engine in and out, see separate service manual: **Section 2 (20-22, 25-26)**.

**Order reference: TP 2103201 (USA/CDN)**  
**TP 2103031 (UK)**  
**Replaces manual: TP 31804/1**

We reserve the right to make alterations without prior notification.

# Important




S135 020

## Torque settings

The torque settings in this manual are shown in two ways:

1. Torque settings in **bold type** (e.g. 'Tighten to **40 Nm**') are used (in **bold**) for components which must be tightened with a torque wrench (plus any angle setting).
2. Torque settings in ordinary type ('Torque setting = 40 Nm') are guidelines only; there is no need to use a torque wrench.





S151 092

## Power screwdrivers

Power screwdrivers must not be used on screw joints with aluminium threads.

There is a major risk of damaging the threads and the component itself.




S147 453

## Threads, repair

In most cases, threads can be repaired using thread inserts.

**Important:** If conical threads are damaged, replace component.

Thread repairs, see 'Thread repairs' on page 41 of this manual.




151 053

## Liquid sealing compound

Engines use liquid sealing compound (P/N 1 161 059-9), e.g. between the upper and lower halves of the cylinder head.

It is essential that the surfaces are thoroughly cleaned and all traces of oil removed before applying new compound.


Apply compound with a short-haired roller (951 1205), covering completely but without any overflow.



150 232

## Suspended engine

**Warning:** Before carrying out work on a suspended engine, ensure that the lifting equipment is **securely attached** and is in **perfect condition**, and check lifting lugs for cracks, loose bolts, etc.




129 826

## Cylinder head, machining

**Important:** Machining to remove scoring or corrosion marks on cylinder head joint face must only be carried out if the head is undistorted.



# Specifications




152 293

## Engine serial and type numbers

The engine serial and type numbers are punched in on the right-hand side of the cylinder block.

There is also a decal on the timing cover, showing the engine type, serial and works number.



## Classification of crankshaft main bearings

This information is punched into the cylinder block and crankshaft.


### Block classification

Crankshaft classification	A small diameter		B medium diameter		C large diameter	
	block		block		block	
	int. sect.		int. sect.		int. sect.	
	block	int. sect.	block	int. sect.	block	int. sect.
A small	yellow medium	yellow medium	yellow medium	blue thick	blue thick	blue thick
B medium	red thin	yellow medium	yellow medium	yellow medium	yellow medium	blue thick
C large	red thin	red thin	red thin	yellow medium	yellow medium	yellow medium

## Compression

Normal value ..... MPa 1.0-1.5

**Note:** Applies with engine warm and throttle wide open, turning starter motor at 4.2 r/s (250-300 r/min).



## Other general data

	B 6244	B 6254	B6304
No. of cylinders .....	6	6	6
Cylinder diameter ..... mm	81.0	81.0	83.0
Stroke ..... mm	77.0	80.0	90.0
Capacity ..... dm <sup>3</sup> (l.)	2.381	2.473	2.922
Firing order .....	1-5-3-6-2-4	1-5-3-6-2-4	1-5-3-6-2-4
Compression pressure ..... MPa(psi)	1.3–1.5(184-213)	1.3–1.5(184-213)	1.3–1.5(184-213)
Max. difference between max./min. values ..... MPa(psi)	0.2(28)	0.2(28)	0.2(28)
Weight, complete (including auxiliaries and oil) .. kg	approx.: 180	approx.: 180	approx.: 180

## Pistons

Engine type	Dimensions in mm		
	A	B	C
B 6244	66.4	42.4	16.0
B 6254	68.8	40.9	16.0
B 6304	59.9	35.9	16.0

## Piston diameter: (D)

Standard	B6244/B6254	B6304
Piston marked C mm	80.98–80.99	82.98–82.99
Piston marked D mm	80.99–81.00	82.99–83.00
Piston marked E mm	81.00–81.01	83.00–83.01
Piston marked G mm	81.017–81.032	83.017–83.032

Overize	B6244/B6254	B6304
Overize 1 mm	81.177–81.192	83.177–83.192
Overize 2 mm	81.377–81.392	83.377–83.392



Max. difference in weight between pistons in same engine: **10 g.**


## Piston clearance

	Minimum	Maximum
Measured cylinder diameter: mm	96.02	96.03
Measured piston diameter mm	-96.01	-96.00
Piston clearance mm	0.01(min)	0.03 (max)

## Piston clearance should be:

B 6244, B6254, B6304 ..... mm 0.01–0.03





146 410

Piston rings

Piston rings, side clearance

Upper compression ring	mm 0.05–0.085
Lower compression ring	mm 0.03–0.065
Oil scraper ring	mm 0.02– 0.055

Dimensions, version 1

Upper compression ring	mm 1.5
Lower compression ring	mm 1.75
Oil scraper ring	mm 3.0

Dimensions, version 2 (1994-)

Upper compression ring	mm 1.2
Lower compression ring	mm 1.75
Oil scraper ring	mm 3.0

Gudgeon pin, diameter	mm 23.0 <sup>+0</sup> <sub>-0.004</sub>
-----------------------	---

**Note:** Later versions of the Volvo 960 have two piston designs, with differences in the upper compression ring. Version 1 can be replaced with version 2 without replacing all pistons; but version 2 must **not** be replaced with version 1.

Piston weight

B6244	g 375±5
B6254	g 380±5
B6304	g 360±5

Valves

A. Valve head diameter

Intake	mm 31.00±0.15
Exhaust	mm 27.00±0.15

B. Valve stem diameter

Intake	mm 6.97 <sup>+0</sup> <sub>-0.015</sub>
Exhaust	mm 6.97 <sup>+0</sup> <sub>-0.015</sub>

C. Overall length


Intake	mm 104.05±0.18
Exhaust	mm 103.30±0.18
Max. machining allowance, valve stem	mm 0.4

D. Valve head height




Intake/exhaust	mm 1.5
Min. height after grinding	mm 1.2

E. Sealing face angle

Intake	44.5°
Exhaust	44.5°



147 529


**Valve stem height**Valve stem height ..... mm **48.5±0.4**Max. machining allowance ..... mm **0.4****Valve seats, angles and width (reconditioned)****Angles:**Sealing face angle, intake/exhaust: ..... **45°**Relief angle, upper: ..... **15°**Relief angle, lower: ..... **60°****Valve seat width:**Intake: ..... mm **1.4–1.8**Exhaust: ..... mm **1.8–2.2****Tappets, dimensions****A** External diameter: ..... mm **32<sup>+0.025</sup><sub>-0.041</sub>****B** External height: ..... mm **26±0.5****Distance between top of tappet and piston****C(1)** Unloaded: ..... mm **18.40****C(2)** Compressed: ..... mm **16.15<sup>+0.3</sup><sub>-0.1</sub>****Valve springs, dimensions**External diameter: ..... mm **26.20**Internal diameter: ..... mm **18.10****Length (mm)****L:** 43.0**L1:** 34.0**L2:** 24.5**Load (N)(lb)**

0 (0)

270±15 (61±3.4)

670±32 (151±7)






21 00061a

## Valve guides, markings and dimensions

Dimension type	Diameter mm	No. of grooves	P/N
Standard	12.0	0	9135628-7
Oversize, no. 1	12.1	1	9135630-3
Oversize, no. 2	12.2	2	9135631-1



146 008


### Clearance between new components:

Intake: ..... mm 0.03–0.06

Exhaust: ..... mm 0.04–0.07

### Max. clearance, used components:

Intake/exhaust: ..... mm 0.15



2100247

## Camshafts

Engine type	Camshaft			
	Markings		Max. lift	
	Intake	Exhaust	Intake	Exhaust
B6244/B6254*	PMI	PHE	7.95	7.95
B6304	PCI	PCE	9.00	9.00

\* Also applies to B 6304 FS2 (USA) with air pump.

## Cylinder head

### Max. distortion:


Longitudinal: ..... mm 0.50

Lateral: ..... mm 0.20


Cylinder head height: ..... mm 129.0±0.05

Max. machining allowance: ..... mm 0.30

**Important:** Machining of the cylinder head to remove scores or corrosion marks on the joint face must only be carried out if the head is undistorted.



S129 826




### Cylinder bore diameter

Standard		B6244/B6254	B6304
Bore marked C	mm	81.00–81.01	83.00–83.01
Bore marked D	mm	81.01–81.02	83.01–83.02
Bore marked E	mm	81.02–81.03	83.02–83.03
Bore marked G	mm	81.04–81.05	83.04–83.05

### Oversize

Oversize 1	mm	81.20–81.21	83.20–83.21
Oversize 2	mm	81.40–81.41	83.40–83.41

Cylinders should be rebored when wear reaches 0.10 mm.




### Crankshaft

Max. throw ..... mm 0.040

Max. axial clearance ..... mm 0.19

Main bearings, radial clearance ..... mm 0.019–0.043



### Crank pins

Diameter, standard ..... mm 50.000  
undersize ..... mm 49.750

Bearing seat width ..... mm 26.000

Max. out-of-round ..... mm 0.004

Max. taper ..... mm 0.004


### Main bearing journals

Diameter, standard ..... mm 65.000  
undersize ..... mm 64.750

Axial bearing seat width ..... mm 26.00

Max. out-of-round ..... mm 0.004


Max. taper ..... mm 0.004



### Connecting rods

Bearing seat diameter,  
big end ..... mm 53.0

Max. out-of-round ..... mm 0.006



133 765

## Oil pump

Relief valve springs

(P/N 1397819)

Load (N)	Length (mm)
----------	-------------

L: 0	76.22
------	-------

L1: 52±4	56.10
----------	-------

L2: 85±8	39.90
----------	-------

(P/N 9135202)

L: 0	76.22
------	-------

L1: 59±4	56.10
----------	-------

L2: 108± 8	39.90
------------	-------



146 578

## Engine oil

Refilling after reconditioning.

**Capacity, incl. oil filter**

B6244, B6254, B6304 ..... **7.00 liter** (7.42 US qt)

## Oil grade

As per API-Service ..... min. SG\*

As per CCMC ..... class G4/G5

\*Oils designated SG/CD meet these requirements.

## Oil pressure (min)\*

12.5 r/s (750 r/min) ..... **MPa 0.10** (14.5 psi)

67.7 r/s (4000 r/min) ..... **MPa 0.35** (49 psi)

Max. oil pressure

(relief valve opening): ..... **MPa 0.70** (99 psi)

(1 kp/cm<sup>2</sup> = 0.10 MPa)

\*Specified oil pressure applies with oil temperature at 100°C, which is reached after 10-15 minutes' running.



150 353

## Thermostat

Markings ..... **87**

Starts opening at ..... **87°C (187°F)**

Fully open at ..... **102°C (216°F)**

Markings ..... **90**

Starts opening at ..... **90°C (194°F)**

Fully open at ..... **105°C (221°F)**

## Torque settings

Torque settings apply with nuts and bolts oiled. Degreased (cleaned) components must be oiled before assembly.

Components	Nm/ (ft. lb)degrees
Exhaust manifold, at cylinder head .....	25 (18)
Exhaust manifold, heat shield .....	15 (11)
Cylinder head, stage 1 .....	20 (15)
stage 2 .....	60 (44)
stage 3 (angle tightening) .....	130°
Cylinder block, intermediate section, stage 1 (M10) .....	20 (15)
stage 2 (M10) .....	45 (33)
stage 3 (M8) .....	25 (18)
stage 4 (M7) .....	17 (13)
stage 5 (M10) (angle tightening) ....	90°
RPM sensor .....	5 (3.5)
Intake manifold .....	20 (15)
Camshaft carrier cover .....	25 (18)
Camshaft pulleys .....	20 (15)
Timing belt, tensioner pulley .....	25 (18)
Timing belt, tensioner mounting .....	25 (18)
Timing belt, idler pulley .....	30 (22)
Knock sensor .....	20 (15)
Coolant pump .....	20 (15)
Carrier plate, stage 1 .....	45 (33)
stage 2 (angle tightening) .....	50°
Torque arm, stage 1 .....	50 (37)
stage 2 (angle tightening) .....	90°
Torque converter .....	40 (30)
Flame trap .....	15 (11)
Oil sump plug .....	35 (26)
Oil pump .....	10 (7)
Oil sump .....	20 (15)
Oil pressure sensor .....	25 (18)
Flywheel, stage 1 .....	45 (33)
stage 2 (angle tightening) .....	65°
Vibration damper, center nut .....	300(221)
Vibration damper, flange bolt, stage 1 .....	35 (26)
stage 2 (angle tightening) .....	60°
Sparkplugs (do not oil) .....	25 (18)
Conrod bearing caps, stage 1 .....	20 (15)
stage 2 (angle tightening) .....	90°
Gearbox, to engine .....	50 (37)




# Universal tools


115	Description - use
8280-6	Milling tool, milling valve seats
8281-4	Piston ring compressor, installing pistons in block

951	Description - use
2015-5	Clamp, used in conjunction with 998 6052
1205-8	Roller, for applying liquid gasket


998	Description - use
5424-2	Piston ring compressor, installing piston rings in block
6052-0	Valve clamp, removing/installing valve collets
8500-6	Belt tension gauge, checking timing belt tension




115 8280-6



115 8281-4



951 2051-5




951 1205-8


080046



998 5424-2




998 6052-0




998 8500-6

# Special tools


999	Description - use
1801-3	<b>Standard handle</b> , for attachment to drifts
2413-6	<b>Counterhold</b> , replacing conrod bushings
2520-8	<b>Stand</b> , for fixtures
2810-3	<b>Lifting yoke</b> , removing/installing engine
5199-8	<b>Counterhold</b> , removing/installing camshaft pulleys
5112-1	<b>Gear segment</b> , locking flywheel
5219-4	<b>Valve guide retainer</b> , removing/installing valve guide seals
5222-8	<b>Gauge</b> , measuring valve stem length
5297-0	<b>Fixture</b> , mounting engine in stand 2520




999 1801-3



999 2413-6




999 2520-8




999 2810-3

08 00431




999 5112-1




999 5199-8



999 5219-4




999 5222-8




999 5297-0


999	Name - use
5309-3	<b>Drift</b> , replacing con rod bushings
5363-0	<b>Fixture</b> , removing/installing valve guides
5364-8	<b>Drift</b> , removing/installing valve guides
5365-5	<b>Drift</b> , removing/installing valve guides
5366-3	<b>Drift</b> , removing/installing valve guides
5367-1	<b>Reamer</b> , reaming valve guides internally
5373-9	<b>Reamer</b> , oversize valve guides
5379-6	<b>Drift</b> , installing valve stem seals
5428-1	<b>Lifting yoke</b> , engine




999 5309-3




999 5363-0



999 5364-8




999 5365-5




999 5366-3

S146 091




999 5367-1




999 5373-9

S146 789



999 5379-6


S146 454



999 5428-1


S150 961

999	Name - use
5429-9	<b>Lifting lug</b> , (B 6304) engine
5430-7	<b>Installation tool</b> , installing rear crankshaft seal
5433-1	<b>Counterhold</b> , removing/installing vibration damper
5449-7	<b>Drift</b> , installing front camshaft seal
5450-5	<b>Drift</b> , installing rear camshaft seal, 4-valve engines (2-valve engines, see tool 5509)
5451-3	<b>Locating tool</b> , aligning crankshaft
5452-1	<b>Locating tool</b> , aligning camshafts
5453-9	<b>Retainer</b> , camshafts, front, 4-valve engines (2-valve engines, see tool 5508)
5454-7	<b>Press tool</b> , installing camshafts




999 5429-9

S150 962




999 5430-7

S152 387




999 5433-1

S152 226




999 5449-7

152 436




999 5450-5

152 437




999 5451-3

152 438




999 5452-1

152 439



999 5453-9

152 440




999 5454-7


152 441




999	Description - use
5455-4	<b>Drift</b> , installing oil pump seal
5456-2	<b>Press tool</b> , compressing belt tensioner
5458-8	<b>Oil filter wrench</b> , removing oil filter
5464-6	<b>Lifting lug</b> , lifting engine (exhaust manifold)
5470-3	<b>Holder</b> (B 6304), removing/installing injectors (California)
5471-1	<b>Holder</b> (B 6304), removing/installing injectors (California)
5502-3	<b>Guide pins</b> (2x), installing bearing shells
5971-0	<b>Base</b> , magnetic stand
9639-9	<b>Dial gauge</b> , measuring tool




999 5455-4



999 5456-2




999 5458-8




999 5464-6

S152 603




999 5470-3

08 00048s




999 5471-1

08 00049s




999 5502-3

21000010



999 5971-0


S152 669




999 9639-9

S152 647


999	Description - use
9684-5	<b>Dial gauge</b> , checking crankshaft straightness
9696-9	<b>Magnetic stand</b> , dial gauge
9701-7	<b>Micrometer</b> , $\varnothing$ 0–25 mm
9702-5	<b>Micrometer</b> , $\varnothing$ 25–50 mm
9703-3	<b>Micrometer</b> , $\varnothing$ 50–75 mm
9704-1	<b>Micrometer</b> , $\varnothing$ 75–100 mm
9802-3	<b>Spring tester</b> , measuring spring load/length



999 9684-5




999 9696-9




999 9701-7

08 00427




999 9702-5

08 00428




999 9703-3

08 00429



999 9704-1

08 00430




999 9802-3

# Reconditioning

## A. Cylinder head, exposure

*Special tools: 999 2520, -2810, -5112, -5297, -5428, -5429, -5459, -5464,*

This procedure starts from lifting out engine as per steps F1-20/21 in service manual: Section 2 (20-22, 25-26) (960)



150 255

A1

### Remove gearbox


*Removing gearbox:* See section 4 (43).

Remove starter motor.

*Automatics:* Remove dipstick and pipe.

Remove torque converter bolts.

We recommend undoing the lower gearbox/engine bolts (which are difficult to reach) before putting the engine assembly on the floor (on a suitable underlay). Take the weight off the gearbox. Undo the remaining bolts and remove the gearbox **carefully**.



150 256


A2

### Remove flywheel/carrier plate

Use gear segment 999 5112.

Remove flywheel.

*Automatics:* Remove carrier plate.



151 067

A3


### Mount engine on stand

Use stand 999 2520 and fixture 999 5297.

Remove lifting tools.

A4


**Stripping, rear end**  
**B 6244, B 6254, B6304**



- |                                |                  |
|--------------------------------|------------------|
| 1. Connector mounting brackets | 5. Coolant hoses |
| 2. Lifting lug (5429)          | 6. Coolant pipe  |
| 3. CMP sensor                  | 7. RPM sensor    |
| 4. ECT sensor                  |                  |

A5


**Stripping, exhaust side**  
**B 6244, B 6254, B6304**



- |                    |                       |
|--------------------|-----------------------|
| 1. Sparkplug cover | 5. Lifting lug        |
| 2. Ignition coils  | 6. RH engine mounting |
| 3. Coolant pipe    | 7. Exhaust manifold   |
| 4. Heat shield     |                       |




**Stripping, intake side  
B6244, B 6254, B6304**



- |   |                                     |
|---|-------------------------------------|
| 1. Injectors and fuel distribution manifold | 5. LH engine mounting and bump stop |
| 2. Intake manifold                          | 6. Oil trap and hoses               |
| 3. Knock sensor (2x)                        | 7. Auxiliaries mounting bracket     |
| 4. Cable harness                            |                                     |

## B. Timing belt and drive assembly, dismantling

Special tools: 998 8500, 999 5433, -5456




152 298

B1

### Align camshaft/crankshaft timing marks

Remove front timing belt cover.

Align timing marks as shown.



152624

B2

### Measure belt tension

Place gauge 998 8500 midway between exhaust camshaft pulley and coolant pump.


Read gauge. Belt tensioner **must** be replaced if reading is **out of limits**.

Belt tension should be within the following limits:

21 mm belt ..... **3.5-4.6 units**

23 mm belt ..... **2.7-4.2 units**

28 mm belt ..... **2.5-3.5 units**



2100227

B3


### Remove vibration damper

Use counterhold 999 5433, attach to vibration damper.

Remove vibration damper.

Remove upper transmission cover.

B. Timing belt and drive assembly, dismantling



B4

**Remove timing belt**

Remove lower belt guard (snowguard).

Undo and remove upper tensioner bolt.


Undo lower belt.

Twist tensioner to free pulley.

Remove lower bolt, tensioner and timing belt.

Check there are no visible leaks.

**Manual engines:** Remove play control washer.




B5

**Compress belt tensioner**

Compress belt tensioner using tool 999 5456. Place tensioner in tool and tighten center tool nut fully. Wait until tensioner is fully compressed (approx. 5 min.) and insert locking pin ( $\varnothing$  2 mm) in piston.

**Note:** Tensioner **must** be replaced if leakage is visible, if there is no resistance to compression or if component cannot be compressed.




B6

**Remove belt drive pulley from crankshaft**

Use universal extractor and two vibration damper bolts. Hand-tighten the two bolts in the pulley as far as they will go.

Attach extractor so that arms act on bolts (not on the pulley itself).

**Note:** Make sure that tool arms do not damage pulley teeth. Check bolts and pulley for any signs of damage.



B7

**Remove tensioner and idler pulleys**

Check pulley surfaces and bearings.

Spin pulleys and listen for noise, check for any play in bearings.

Check that pulley surfaces are smooth and clean.

B8


**Remove oil pump**

Remove four oil pump mounting bolts.

Pry pump off **carefully**, using a screwdriver inserted behind the prising lug.

Clean joint faces and mating surfaces.

Remove oil cooler thermostat casing.



2100250


B9

**Dismantle oil pump**

Clean and inspect all components.

Inspect components for damage and wear, paying particular attention to half-moon-shaped insert (surface between suction and delivery sides). Replace complete pump if any component is defective.

(Relief valve parts available separately.)



151 564

B10

**Test relief valve springs:**

(P/N 1397819)

Load (N)	Length (mm)
0	76.22
52±4	56.10
85±8	39.90

(P/N 9135202) later version

0	76.22
59±4	56.10
108±8	39.90

133 765


B11

**Put pump wheel in casing and check for clearance/play**

Lay large pump wheel in position with marking facing upwards.

Put small wheel in position.


Check clearance/play. If excessive, replace complete pump. Reassemble pump.



151 565

**Important:** If the measured clearance between the outer rotor and casing is greater than 0.35 mm and the oil pressure is less than 1 bar (14.5 psi) at an oil temperature of 100°C (112°F), the oil pump should be replaced. Measure clearance with a feeler gauge.


B. Timing belt and drive assembly, dismantling



B12

**Remove coolant pump and inner transmission cover**

Remove coolant pump.  
Clean joint face and mating surfaces, removing all remains of original gasket.  
Remove inner transmission cover.




B13

**Greasing automatic tensioner pulley (Applies to earlier types)**

Remove center tensioner bolt and dismantle as shown in picture.  
Apply grease P/N 1 161 246-2 (50g) or 1 161 247-0 (500g) between friction plate and cover, and to the four spring holes (arrowed).  
Reassemble belt tensioner, tighten center bolt. **20 Nm (15 ft.lb.)**.


For later types: replace tensioner if necessary.



B14

**Remove coolant thermostat**

Remove thermostat and gasket (Torx 40 bolts).  
Clean joint faces and mating surfaces.  
Remove thermostat casing.



B15

**Thermostat, checking opening**

Thermostat can be tested in hot water.  
Maximum opening should be reached in two minutes in water at specified opening temperature.

Marking	87
Starts opening at	87°C (187°F)
Wide open at	102°C (216°F)
Marking	90
Starts opening at	90°C (194°F)
Wide open at	105°C (221°F)

## C. Cylinder head, removal

Special tool: 999 5199


C1

### Remove camshaft pulleys

Mark pulleys (intake and exhaust).

Use counterhold 999 5199.

**Important:** Camshaft pulleys **must not be rotated** when removing timing belt, as this may damage valves.




C2

### Remove top half of cylinder head

Remove all bolts.

Undo bolts (from inside and out).

Tap top half off **gently** with a plastic mallet by prying lugs and front ends of camshafts.




C3


### Remove camshafts

Twist camshafts and lift out simultaneously. Avoid damaging axial guides.

(This makes taking the camshafts out of the axial guides easier.)








C4

### Remove cylinder head

Undo bolted joints (working from outside and in).

Remove cylinder head and gasket from cylinder block.



C5

### Clean mating faces

Clean mating faces on upper and lower halves of cylinder head.

Use gasket remover P/N 1 161 340-3.


Scrape surfaces clean **carefully** using a soft putty knife.

Rinse clean with water and dry surfaces with alcohol.

**Note:** Always use a fume hood or extractor when using gasket remover.



## D. Crank mechanism, dismantling



D1

### Remove oil sump


Remove oil filter.

Disconnect flame trap return line.

Remove oil sump.

Tap sump off **carefully** using a plastic mallet.

Remove oil passage oil rings.




D2

### Remove oil pump suction pipe

Clean and inspect pipe and strainer.

Remove O-ring.



D3


### Remove intermediate section

Undo intermediate section bolts, working from the sides inwards towards the center.

Tap intermediate section off **carefully** with a plastic mallet.

Remove rear crankshaft seal.

**Important:** Do **not** let crankshaft rotate.




D4

#### Remove big end bearing caps

Check markings on caps and conrods. Mark with center or number punch as required.

Check centering of bearing halves on conrods and caps.

**Important:** Do not mix up bearing shells for different crankshaft bushings. Do **not** rotate crankshaft.



D5


#### Lift crankshaft out of engine block

Support crankshaft in V-blocks on outermost two main journals.

Remove remaining main bearing shells from block.

Mark position of thrust bearing.

**Note:** Do not mix up bearing shells from the different main journals.




D6

#### Remove pistons from engine block

Push pistons **carefully** by hand to overcome friction from rings.

Remove pistons and conrods from bores.



D7

#### Clean joint faces

Clean joint faces on cylinder block, intermediate section and oil sump.

**Carefully** scrape surfaces clean with a soft putty knife.

Use gasket removed P/N 1 161 340-3 if necessary.

**Note:** Always use a fume hood or extractor when using gasket remover.

## E. Cylinder block, measurement

Special tool: 999 9639, -9704

E1


### Measure cylinder bores

Wipe bores clean and inspect visually.

Measure bores using dial gauge 999 **9639** (50–100 mm), micrometer 999 **9704** and a micrometer stand.

Set micrometer to bore diameter plus **max.** tolerance as marked on block.

Calibrate dial gauge using micrometer.




146 406

E2

### Measure wear

Measure **maximum wear** at right angles to engine centerline immediately underneath TDC.

Measure **minimum wear** in line with centerline at BDC.



152647

E3

### Classification

Each cylinder is identified by a classification marking (C,D,E or G) punched in the rear of the block.

Oversize bores are indicated by abbreviations OS1 or OS2 as appropriate. This marking must be applied after reboring.


### Cylinder bore diameter

Standard	B6244/B6254	B6304
Bores marked C mm	81.00–81.01	83.00–83.01
Bores marked D mm	81.01–81.02	83.01–83.02
Bores marked E mm	81.02–81.03	83.02–83.03
Bores marked G mm	81.04–81.05	83.04–83.05

### Oversize

OS1	mm	81.20–81.21	83.20–83.21
OS2			

Cylinders should be rebored when wear reaches 0.10 mm.




152648

F. Crank mechanism, measurement

Special tools: 998 5424, 999 2413, -5309, -9696, -9684, -9701, -9702, -9703, -9704

Crank mechanism, measurement	F1–12
Conrod bushings, replacement	F13–16




F1

Measure crankshaft

Use micrometer 999 9703.

Measure out-of-round and ovality of bearing journals. Measure at several points around circumference and along length.




F2

Crank pins

Diameter, standard	mm 50.000
undersize	mm 49.750
Bearing seat width	mm 26.000
Max. out-of-round	mm 0.004
Max. ovality	mm 0.004

Main bearing journals

Diameter, standard	mm 65.000
undersize	mm 49.750
Axial bearing seat width	mm 26.000
Max. out-of-round	mm 0.004
Max. ovality	mm 0.004



F3

Check crankshaft straightness

Use dial gauge 999 9684 and magnetic stand 999 9696.

Support outermost main bearing journals in V-blocks.


Turn crankshaft and measure radial throw of other main bearing journals.

Max. radial throw mm 0.004

F4



146 409



146 410

### Remove piston rings

Use piston ring pliers 998 **5424**.

Remove carbon deposits. Clean piston ring grooves by scraping with a scraping tool or fragment of ground piston ring.

Check for:

- damage
- wear
- cracking

F5

### Check piston ring side play

Use **new** rings.

Upper compression ring: ..... **mm 0.05-0.085**

Lower compression ring: ..... **mm 0.03-0.065**

Oil scraper ring: ..... **mm 0.02-0.055**

#### Dimensions, version 1

Upper compression ring ..... **mm 1.5**

Lower compression ring ..... **mm 1.75**

Oil scraper ring ..... **mm 3.0**

#### Dimensions, version 2 (1994-)

Upper compression ring ..... **mm 1.2**

Lower compression ring ..... **mm 1.75**

Oil scraper ring ..... **mm 3.0**

F6

### Measure piston diameter

Use micrometer 999 **9704** and sliding calipers.

A = Overall piston height.

B = Height from gudgeon pin center to crown.

C = Measure piston diameter at right-angles to gudgeon pin hole at distance C from edge of skirt.

D = Diameter.

Dimensions A, B and C, see table.


#### Piston diameter (D)

Standard	<b>B6244/B6254</b>	<b>B6304</b>
Piston marked C <b>mm</b>	80.98–80.99	82.98–82.99
Piston marked D <b>mm</b>	80.99–81.00	82.99–83.00
Piston marked E <b>mm</b>	81.00–81.01	83.00–83.01
Piston marked G <b>mm</b>	81.017–81.032	83.017–83.032

#### Översize


Oversize 1	<b>mm</b>	81.177–81.192	83.177–83.192
Oversize 2	<b>mm</b>	81.377–81.392	83.377–83.392

Max. difference in weight between pistons in same engine: ..... **10 g**



137 551

Engine type	Dimensions in mm		
	A	B	C
B 6244	59.9	35.9	16.0
B 6254	59.9	35.9	16.0
B 6304	59.9	35.9	16.0



F7


Calculate piston clearance

*Measured		B6244/B6254	B6304
cylinder diameter	mm	96.02	96.03
Measured			
piston diameter:	mm	-96.01	-96.00
piston clearance =	mm	0.01 (min)	0.03 (max)

Piston clearance should be:

B 6244, B 6254, B 6304 .....mm 0.01–0.03

\*For measurement of cylinder bores see steps E1–E3.



F8

Separate conrods and pistons

First check that piston and conrod are marked. (Conrod see step D4).

Pry circlip out **carefully** with a screwdriver. Push gudgeon pin out by hand.

Clean and inspect conrods, bearing caps and bolts for damage, wear and cracking.

Check length of conrod bearing cap bolts using sliding calipers.

Max. length ..... mm 55



F9

Check gudgeon pin fit in pistons

No play is allowed. Gudgeon pin should slide gently but firmly through hole when pressed with thumb.

If there is any play, replace piston.



F10

Check gudegon pin fit to conrods


Gudgeon pin should slide through hole when pressed gently with thumb.

If excessive play, measure gudgeon pin and fit new conrod bushing if necessary.

Use micrometer 999 9701.

Gudgeon pin diameter:

B 6244, B 6254, B 6304 ..... mm 23.0<sup>+0</sup><sub>-0.004</sub>



152654

F11

**Check bearing seats at big end of conrod**


Inspect bearing shells visually.

If in doubt, measure out-of-round.

Use dial gauge 999 9639.

**Bearing seat diameter:**

B 6244, B 6254, B 6304 ..... mm 53.0

**Max. out-of-round** ..... mm 0.006

116 220

F12

**Check conrod in alignment gauge**

Check straightness and twisting.

**Important:** Check that clamping surface of fork is round and free of burrs.

Release and tighten expander at big end between each alignment check.

**Conrod bushings, replacement**

Steps ..... F13-F16


F13

**Press bushing out**

Use drift 999 5309.


Position drift correctly with short end downwards.

Use drift 999 2413 as counterhold.



141 328





F14

### Press in new bushing

Use drift 999 5309.

Position drift correctly, long end downwards.

Push drift right down.

**Important:** Make sure that hole in bushing is aligned with lubricating passage in conrod.




F15

### Check gudgeon pin fit to new bushing.

Gudgeon pin should slide through bushing under light thumb pressure, but without noticeable play.

Machine bushing as necessary.




F16

### Check conrod in alignment gauge

Check for straightness and twisting.

**Important:** Check that clamping surface of fork is round and free of burrs. Release and tighten expander at big end between each alignment check.



F17

### Conrod, replacement


Conrods are symmetrical and can be turned over if required.

**Markings:** Assemble conrod (tighten bolts to **20 Nm (15 ft.lb.)**) and check that bearing cap is correctly positioned.

Put big end in clamp using copper spacers or similar tool. Mark both halves with the cylinder number using a center or number punch.

## G. Cylinder head, measurement/reconditioning

Special tools: 115 8280, 951 2051, 998 6052, 999 5219, -5222, -5363, -5364, -5365, -5373, -5379, -5505, -9802



152655


G1

### Remove tappets (valve lifters) from cylinder head

Use magnet or suction cup to assist in removing tappets.

Check tappets for signs of wear. Measure as required.

**Note:** Store tappets upside down to prevent oil draining out. Ensure tappets are placed in order - do not interchange components. Put tappets in oil-filled container if storing for any length of time.



147 414

### Tappet dimensions


A External diameter: ..... mm  $32^{+0.025}_{-0.041}$

B External height: ..... mm  $26 \pm 0.5$

### Distance between top of tappet and piston

C(1) Unloaded: ..... mm 18.40

C(2) Compressed: ..... mm  $16.15^{+0.3}_{-0.1}$



152656

G2

### Remove valves


Use valve clamp 998 6052 and clamp 951 2051.

Remove:

- valve collets
- upper spring collars
- valve springs
- valves

**NOTE:** Check positions of moving parts carefully.

G3



152657

### Remove valve stem seats


Use tool 999 **5219**.

Remove seals and lower spring collars.

Clean cylinder head:

- joint faces
- combustion chambers
- intake/exhaust ports
- valve seats

G4



2100256

### Check cylinder head

Clean sparkplug socket threads (use M14×1.25 tap).  
Clean valves, valve springs and spring collars.

Check visually for damage.

If in doubt as to whether valve seats are cracked, mill seat clean using tool 115 **8280** with Ø7 mm spindle and 45° cutter.

#### Air intake ducts, cleaning:

(1995 models onwards)

Scrape hole clean (Ø 4 mm) as far as possible. Blow air intake ducts clean with compressed air from intake side, on top of cylinder head. Check that air is getting through.

**Note:** Check that the reaming tool does not come into contact with the combustion chamber walls.

### Valve seat width

Intake ..... mm **1.4-1.8**

Exhaust ..... mm **1.8-2.2**

G5

### Measure cylinder head distortion

Use steel rule and feeler gauges.

Max. distortion:


Longitudinal ..... mm **0.50**

Lateral ..... mm **0.05**


Cylinder head height: ..... mm **129.0±0.05**

Max. machining allowance: ..... mm **0.30**

**Important:** Only machine cylinder head to remove scoring or corrosion on joint faces if head is undistorted.



129 826



146 008

G6

**Measure valve guide wear**

Use magnetic stand and dial gauge. Lift valve **approx. 2-3 mm** clear of seat when checking guide.


Clearance between new components:

Intake: ..... **mm 0.03-0.06**

Exhaust: ..... **mm 0.04-0.07**

**Max. clearance, used components:**

Intake/exhaust: ..... **mm 0.15**



146 009

G7

**Measure valve springs**

Measure spring load using tester 999 **9802**.

External diameter: ..... **mm 26.2**

Internal diameter: ..... **mm 18.1**

Length (mm)	Load (N)
<b>L:</b> 42.0	0
<b>L1:</b> 34.0	270±20
<b>L2:</b> 24.5	640±40

G8

**Valves, measurement****A. Valve head diameter**

Intake ..... **mm 31.00±0.15**

Exhaust ..... **mm 27.00±0.15**

**B. Valve stem diameter**

Intake ..... **mm 6.97<sup>+0</sup><sub>-0.015</sub>**

Exhaust ..... **mm 6.97<sup>+0</sup><sub>-0.015</sub>**

**C. Overall length**

Intake ..... **mm 104.05±0.18**

Exhaust ..... **mm 103.30±0.18**

Max. machining allowance, valve

stem ..... **mm 0.4**

**D. Height of valve head**


Intake/exhaust ..... **mm 1.5**

Min. height after grinding ..... **mm 1.2**


**E. Sealing face angle**

Intake ..... **44.5°**

Exhaust ..... **44.5°**



147 529



## Valve guides, replacement


G9

### Mount cylinder head on fixture 999 5363

Adjust angle of inclinations using holes at top of fixture ends.

Clamp head to fixture using any of the holes so that the drift is vertical when pressed in.

Use four sleeves as spacers for cylinder head bolts.




### Press out guides to be replaced

G10

#### 1. Press out guides using drift 999 5364

Press slowly until drift bears against valve spring seat.

Remove any metal clips if guide is damaged.




G11

#### 2. Press down further using drift 999 5365

Inspect upper section of guide bore.

Oversize guide **must** be installed if guide bore is scored. See step G14.




G12

#### 3. Place new valve guide on drift 999 5505 and press home

Press guide **slowly** into head until drift bears against valve spring seat.

Top of guide should project by: ..... mm  $13 \pm 0.2$   
Height is set by tool.

**Important:** Pressure should be at least **9000 N**. If less force is required, remove guide, ream out bore and install oversize guide.




G13

**Valve guides, markings and dimensions**

Dimension type	Diameter mm	No. of grooves	P/N
Standard	12.0	0	9135628-7
Oversize, no. 1	12.1	1	9135630-3
Oversize, no. 2	12.2	2	9135631-1

G14

**To install oversize guide, ream out hole with reamer 999 5373**


**Note:** Reamers come in two sizes (oversize 1 and 2). Oversize no. 1 can often be pressed home without reaming. See 'pressure'.

**Dressing valve seats**

G15

**Mill valve seats****Angles:**Sealing face angle, intake/exhaust: . . . . . **45°**Relief angle, upper: . . . . . **15°**Relief angle, lower: . . . . . **60°**

Valve seat width: a

Intake . . . . . **mm 1.4-1.8**Exhaust . . . . . **mm 1.8-2.2**


**Note:** Check that milling cutter is clear of combustion chamber walls.

**Dressing valves**


G16

**Grind intake valves**Seating face angle: . . . . . **44.5°**Edge width, new valve: . . . . . **mm 1.5**Min. edge width after grinding: . . . . . **mm 1.2**

**Important:** Exhaust valves are stellite coated and must be ground only with grinding paste (by hand).







G17

**Check valve stem height**

Use gauge 999 **5222**.

Place gauge across camshaft bearing seats.

Measure valve stem height by inserting sliding calipers through hole in gauge.

Valve stem height: ..... mm **48.5 ±0.4**

Max. machining allowance, valve


stem: ..... mm **0.4**

**Length, new valve**

Intake: ..... mm **104.5±0.18**

Exhaust: ..... mm **103.3±0.18**

**Note:** Correct valve stem **height** is essential if the hydraulic tappets are to work properly.

**Valves, installation**


G18

*Grease valve stems and guides.*

**Install valves**

- lower valve spring collars
- valves (in correct positions)

Mount protective sleeve (included in gasket kit) on valve stem.



G19


**Install valve stem seals**

Place seal on valve stem.

Remove protective sleeve.

Push seal onto stem **by hand only** as far as possible.  
Use drift 999 **5379**.

**Caution:** Do **not** use a hammer to fit valve stem seals, otherwise damage may result.



G20


**Install:**

- valve spring and upper spring collar using clamp 998 **6052** and clamp 951 **2051**.
- collets: check that both halves are properly in position when the spring is not under load.



## H. Threads, repair

Repairs to internal threads in the cylinder block, intermediate section and cylinder head are carried out with the aid of thread inserts. Some threaded holes cannot be repaired in this way because the threads are too fine. (Holes which should not be repaired are also included in the tables below.)



21 00075A

### Thread inserts

Thread inserts are made of cold-rolled wire sectioned to ISO thread standards. The material used is stainless, acid-resistant steel. Inserts are designed to be fitted in holes which are drilled and threaded as per the standard thread insert tables.

Thread inserts have a handle with breaking instructions. This handle must be knocked off after installation.


### Procedure:

H1

#### Drill out the hole to be repaired

Use a drill diameter and length taken from the thread insert tables on pages 43, 46 and 48.

Do **not** lower the edges of holes; we recommend only a slight angling.



21 00067A

H2

#### Thread the hole using the die for the thread insert


Use the right die for the material and work concerned.

When working on an M10 threaded hole, use a die for an **M10 thread insert**.


Thread down to the right depth (see table).

Blow hole clean.

Use correct length thread insert (see table).



21 00068A




21 00070A

### Insert thread insert in fitting tool

Insert the insert with the handle downwards.

H3



21 00069A


### Install thread insert

Hold fitting tool immediately over the threaded hole.

Wind thread insert in until approximately one complete turn remains projected out of the hole.

If a hole goes right through, the thread insert must not project out of the bottom of the hole.

H4



21 00072A

### Knock off fitting pin

Knock handle off with pin hammer. Do **not** use the fitting tool to knock the handle off.

Remove handle and blow hole clean.

Using a bolt, check that the thread is clear and that the thread insert is installed correctly.





H5


## Repairs to cylinder head and camshaft casing

The table below shows which holes in the cylinder head and camshaft casing can be repaired and which thread inserts to use.

The table also shows drilling depth and diameter and the part numbers for each thread insert.


Existing threads		For repairs use thread inserts						Use	Holes as shown in diagrams on pages 44 and 45
Qty	Thread dim.	Thread dim.	Length mm	P/N thread insert	Drill diam. mm	Drilling depth mm	Min. thread depth mm		
1	M12-6H	M12×1.75	12	956026-9	12.5	24	12	Engine coolant temp sensor	BV11
3	M5-6H	M5×0.8	10	956011-1	5.3	15	10	Distributor	BV18, BV19, BV25
2	M7-6H7H	M7×1	17.5	947845-4	7.4	21.5	17.5	Camshaft pos. sensor	BV21, BV28
2	M10-6H	M10×1.5	20	956023-6	10.4	28	20	Lifting lug	BV30, BVBB
1	M5-6H	M5×0.8	10	956011-1	5.3	15	10	Ground bolt	BV31
3	M7-6H7H	M7×1	17.5	947845-4	7.4	21.5	17.5	Thermostat housing	V14-16
9	M7-6H7H	M7×1	17.5	947845-4	7.4	21.5	17.5	Intake manifold	V17-25
2	M7-6H7H	M7×1	17.5	947845-4	7.4	21.5	17.5	Timing belt cover rear	F10-11
2	M7-6H7H	M7×1	17.5	947845-4	7.4	21.5	17.5	Bypass pipe	H13-14
12	M8-6H7H	M8×1.25	16	965158-9	8.4	24	16	Exhaust manifold	H15-H26
2	M6-6H7H	M6×1	9	956014-5	6.3	16	9	Timing belt cover, upper	TT1-2
12	M6-6H7H	M6×1	9	956014-5	6.3	16	9	Ignition coils	T115-126
6	M6-6H7H	M6×1	9	956014-5	6.3	16	9	Sparkplug cover	T133-136, T139-140
46	M7-6H7H	M7×1	17.5	947845-4	7.4	16	17.5	Camshaft casing	T29-34, T36, T38-73, T75, T77-78





Top view, cylinder head

21 00088A



Top view camshaft casing

21 00089A


## Repairs to cylinder block and intermediate section

The table below (contd. on page 48) shows which threaded holes on the cylinder block (CB) and intermediate section (IS) can be repaired and which thread inserts to use.

The table also shows drilling depth and drill diameter and the part numbers for the respective thread inserts.


**Note:** Do not repair holes marked **V3** with thread inserts.

Existing threads		Can be repaired with thread inserts						Use	Holes as marked on diagrams on page 47
Qty	Thread dim.	Thread dim.	Length mm	P/N thread insert	Drill diam. mm	Drill depth mm	Min. thread depth mm		
33	M7-6H7H	M7×1	14	941843-5	7.3	18	14	Oil sump	B40-69, B79, B81-82
2	M7-6H7H	M7×1	14	941843-5	7.3	18	14	Oil sump pipe	B71, B78
14	M10-6H8H	M10×1.5	25	956024-4	10.5	33	25	Intermediate section, bearing shells	B7-20
14	M8-6H7H	M8×1.25	16	956019-4	8.4	24	16	Intermediate section	B21-34
6	M7-6H7H	M7×1	14	941843-5	7.3	18	14	Intermediate section	B41-46
1	M8-6H7H	M8×1.25	16	956019-4	8.4	24	16	Starter motor	V10
4	M8-6H7H	M8×1.25	16	956019-4	8.4	24	16	Engine mounting	V11-12, V35-36
6	M8-6H7H	M8×1.25	16	956019-4	8.4	24	16	Auxiliaries	V21-22, V26-27, V31-32
2	M8-6H7H	M8×1.25	16	956019-4	8.4	24	16	Knock sensor	V37-38
1	M8-6H7H	M8×1.25	16	956019-4	8.4	24	16	Oil dipstick	V16
3	M8-6H7H	M8×1.25	16	956019-4	8.4	24	16	EGR valve	V17-19
3	M8-6H7H	M8×1.25	16	956019-4	8.4	24	16	Electrical ground	V15, V33-34
1	M16	<b>Must not be repaired</b>						Crankshaft setting	V3
1	M14	M14×1.5	20	967576-0	14.2	24	21	Oil pressure switch	V4
2	M7-6H7H	M7×1	14	941843-5	7.3	18	14	Oil trap	V40, V41 P/N (bolt): 977636




21 00082A

**Underside view, intermediate section**



21 00083A

**Underside view, cylinder block**



**LH side, cylinder block and intermediate section**

21 00081A




## Further repairs, cylinder block and intermediate section

The table below (continued from page 46) shows which threaded holes in the cylinder block (CB) and intermediate section (IS) can be repaired and which thread inserts to use. It also shows the drilling depth, drill diameter and part number for each thread insert.

**Note:** Holes marked H4, H5, BV3, BV5, BV10 and BV21 must not be repaired using thread inserts.


Existing threads		Can be repaired with thread inserts						Use	Holes marked as shown in diagrams on page 49
Qty	Thread dim.	Thread dim.	Length mm	P/N thread insert	Drill diam. mm	Drilling depth mm	Min. thread depth mm		
4	M8-6H7H	M8×1.25	16	956019-4	8.4	24	16	Engine mounting	H9, N16, H18, H19
2	M8-6H7H	M8×1.25	16	956019-4	8.4	24	16	Turbo stage	H10, H11
2	M8-6H7H	M8×1.25	16	956019-4	8.4	24	16	Electrical ground	H17, H20
1	M14	M14×1.5	20	967576-0	14.2	24	21	Turbo oil pressure	H3
1	1/4"	<b>Must not be repaired</b>						Coolant drain	H4
1	1/4"	<b>Must not be repaired</b>						Parking heater	H5
1	M8-6H7H	M8×1.25	16	956019-4	8.4	24	16	Coolant pipe	H13
14	M12-6H8H	M12×1.75	24	956028-5	12.5	34	24	Cylinder block	T10-23
1	M7-6H7H	M7×1	14	941843-5	7.3	18	14	Timing belt cover	F16
2	M7-6H7H	M7×1	14	941843-5	7.3	18	14	These holes omitted	F15, F17
3	M8-6H7H	M8×1.25	16	956019-4	8.4	24	16	Engine mounting	(F11-13) *
5	M8-6H7H	M8×1.25	16	956019-4	8.4	24	16	Timing belt tensioner	F10, F14, F25, F26, F28
7	M7-6H7H	M7×1	14	941843-5	7.3	18	14	Coolant pump	F18-24
4	M7-6H7H	M6×1	12	956015-2	6.3	19	12	Oil pump	F30-33
3	M12	<b>Must not be repaired</b>						Mounting bracket VPK (gearbox)	BV3, BV5, BV10
3	M10-6H8H	M10×1.5	20	956023-6	10.5	28	20	Gearbox	BV4, BV6, BV7
2	M10-6H8H	M10×1.5	20	956023-6	10.5	28	20	Torque arm	(BV8, BV9) *
2	M7-6H7H	M7×1	10.5	948015-3	7.3	14.5	10.5	RPM sensor	BV15, BV16
1	3/8"	<b>Must not be repaired</b>						Passenger compartment heater	BV21
1	M7-6H7H	M7×1	14	941843-5	7.3	18	14	Coolant pump intake pipe	H60 P/N (bolt): 968814

\*) 5-cylinder engines only




**RH side, cylinder and intermediate section**

21 00077A




**Top view, cylinder block**

21 00078A



**Front view, cylinder block and intermediate section**

21 00079A



**Rear view, cylinder block and intermediate section**

21 00080A

## I. Hermetically sealed bolts, sealing

Hermetically sealed bolts are used where a perfect seal is required. Replace bolts once undone or seal with new sealing compound. HYDRAULIC THREAD SEALING COMPOUND part number is **11 61 056-5**; follow instructions on pack. This service bulletin includes a list and illustrations of hermetically sealed bolts on the B6304 engine.

11



2100121S

### Sealing compound

#### Hydraulic thread sealing compound


- P/N 11 61 056-5
- Apply sealing compound to bolts using brush or pipe on pack.
- Avoid sealing compound coming into contact with skin.

**Bolts to be sealed with HYDRAULIC THREAD SEALING COMPOUND.**

12

**Engine intake side**

Position	Description	Qty.	P/N
A	Auxiliaries bracket bolt	1	946671-5
B	Engine mounting bolt	1	948217-5
B	Engine mounting bolt	1	948217-5
C	Starter motor mounting bolt	1	946440-5
D	Cable mounting bolt	1	946173-2




2100121A

Bolts to be tightened with HYDRAULIC THREAD SEAL COMPOUND.

13

Engine exhaust side

Position	Description	Qty.	P/N
A	Coolant pipe bolt	2	975880-6
B	Coolant pump casing plug	1	968144-6
C	Drain plug	1	9135268-2




2100122A

**Bolts to be tightened with HYDRAULIC THREAD SEALING COMPOUND.**

14

**Engine rear**

	Description	Qty.	P/N
A	Nipple bolt	1	1397915-8




2100122A

15

**Engine front**

	Description	Qty.	P/N
A	Coolant pump bolt	7	977744-2
B	Oil thermostat housing bolt	2	975883-0




2100122A

## J. Crank mechanism, reassembly

Special tools: 999 1801, -5430, -5502, -5971, -9696

Universal tools: 115 8281, 951 1205, 998 5424



J1

### Classification of crankshaft main bearings

Clean main bearing seats.

Check that components are clean and undamaged.

Check classification on cylinder block and crankshaft.

Each main bearing seat is marked with the cylinder number and a classification letter for the block and crankshaft. Use the table below to select the right bearing.

Block classification

	A small diameter		B medium diameter		C large diameter	
	block	int. sect.	block	int. sect.	block	int. sect.
<b>A</b> small	yellow medium	yellow medium	yellow medium	blue thick	blue thick	blue thick
<b>B</b> medium	red thin	yellow medium	yellow medium	yellow medium	yellow medium	blue thick
<b>C</b> large	red thin	red thin	red thin	yellow medium	yellow medium	yellow medium

Crankshaft classification

J2

### Selecting bearing

Install main bearing in cylinder block as in table.

Oil bearing shells liberally on crankshaft side.


Install flanged shells in rearmost position.

*E.g.: Classifying no. 1 bearing.*

*Marking on block is B.*

*Marking on crankshaft is C.*

*Install a **red** bearing in the block and a **yellow** bearing in the intermediate section.*



J3

### Intermediate section

Apply liquid sealing compound (1 161 059-9) to intermediate section. Cover entire surface, but do not allow to overflow, as this may block ducts and bolt holes.


Use short-haired roller 951 1205.

Place bearing shells in intermediate section (make sure bearing shells are dry between bearing and block. otherwise bearing may rotate along with crankshaft).

Oil bearing shells and flange bearing (furthest back) generously.



J4



### Install crankshaft

Install crankshaft. Do **not** turn crankshaft before intermediate section has been tightened.


Put intermediate section in position.

Tighten intermediate section/crankshaft bolts in five stages in numerical order as shown in picture. Each stage must be complete before starting the next.

1. Tighten all M10 bolts to ..... **20 Nm** (15 ftlb)  
(skip M8 and M7 until stages 3 and 4.)
2. Tighten M10 bolts to ..... **45 Nm** (33 ftlb)
3. Tighten M8 bolts to ..... **24 Nm** (18 ftlb)
4. Tighten M7 bolts to ..... **17 Nm** (13 ftlb)
5. Finally, tighten M10 bolts ..... **90°**

Max. length of M10 bolts: . . . . . mm 118
--

J5



### Measure crankshaft end float

Check that crankshaft turns smoothly.

Measure end float.

Use dial gauge, magnetic plate 999 **5971** and magnetic stand 999 **9696**.

End float: ..... mm **0.08-0.19**

J6


### Install crankshaft rear seal

Use standard handle 999 **1801** and assembly tool 999 **5430**.

Oil mating surfaces between seating flange and seal, and between seal lips. Place seal on drift.


If there are wear marks on crankshaft, push seal further in than before by removing a spacer from the tool.

Tap seal in until drift meets crankshaft.






**Note:** Insert circlip and check that ring springs apart and locks in groove. Circlip opening should point downwards.



S152 672



2100287A

### Assemble pistons and conrods

Arrow on piston crown must point forwards, i.e. towards timing belt end of engine. Number markings on conrods must face towards intake side of block (starter motor side).

**Piston, replacement:** Later Volvo 960 models have two types of piston, which differ in terms of their upper compression rings. Version 1 can be replaced by version 2 without having to replace all pistons; but version 2 must **not** be replaced by version 1.

**Conrod, replacement:** Conrods are symmetrical and can be used either way round.

**Markings:** Install conrod (tighten bolts to **20 Nm** (15 ftlb)) and check that bearing cap is pointing in the right direction. Put big end in a vice with copper inserts or similar. Mark both halves with the cylinder number using a number punch or die.

J7

### Install piston rings

Use piston ring pliers 998 **5424**. Turn piston rings so gaps are approx. **120°** apart.

Piston rings, dimensions: See specifications p.6.

- A.** Upper compression ring: *Text facing upwards*
- B.** Lower compression ring: *Groove facing downwards*
- C.** Oil scraper ring: *Text facing upwards*

Clean and dry bearing seats in conrods and caps.

Install bearing shells in conrods and caps.

Install guide pins 999 **5502**.

**Important:** If reusing **original** bearing shells, components **must** be located in original positions.

J8

### Install pistons in bores

Use piston ring compressor 115 **8281**.

Oil cylinder bores, pistons and bearing shells.


When fitting each piston, turn crankshaft so crank pin is at its lowest position to fit the piston in.

Check that piston classification is correct.


Press piston down (e.g. with hammer shaft).

**Note:** Arrows on piston crown **must** point towards front, i.e. timing belt, end of engine.

J9



152673



### Install bearing caps

Remove guide pins (5502) and install caps.

**Note:** Do **not** turn crankshaft until conrod bearing caps have been tightened.


Check that conrod and bearing cap markings match.

Use **new** bolts. Oil bolts, and tighten in two stages:

1. **20 Nm** (15 ftlb)
2. Plus **90°**

Check that conrods are free to move laterally.

J10



### Install oil pump suction pipe


Put gasket on pipe.

Reconnect pipe.

Tighten to **17 Nm** (13 ftlb).

Install **new** oil passage seals.

J11



### Install oil sump

Apply liquid sealing compound (P/N 1 161 059-9) to sump. Use short-haired roller 951 **1205**.

**Important:** Insert four bolts and align sump flush with rear face of block. Permitted tolerance  $\pm 0.025$  mm.


Tighten bolts back and front to **17 Nm** (13 ftlb).

Install **new** oil filter.

J12

## K. Cylinder head, installation

Special tools: 999 1801, -5449, -5451, -5452, -5453, -5454




K1

### Lock crankshaft in position

Use crankshaft locking tool 999 **5451** at rear of engine (see picture).

Turn crankshaft counterclockwise until counterweight meets stop.

Check that piston in last cylinder (5 or 6) is midway between TDC and BDC.




K2

### Install tappets

Tappets **must** be reinstalled in original positions, and oiled

**Note:** If tappets have leaked oil, top them up with an oilcan or similar via the hole in the side.



K3

### Install lower cylinder head section


Use **new** cylinder head gasket.

Max. length of M12 bolts: ..... **158 mm**

Oil bolts. Tighten bolts as follows, starting from center and working outwards:

1. **20 Nm** (15 ftlb)
2. **60 Nm** (44 ftlb)
3. **150°**

Install new O-rings around sparkplug wells.




K4

**Apply liquid sealing compound**

Apply liquid sealing compound (1 161 059-9) to camshaft carrier, using short-haired roller 951 1205.


**Note:** Make sure no sealing compound gets into coolant or oil passages.



K5

**Install camshafts**

Install camshafts. Fix camshafts in position using retainer 999 5453 at front end and locating tool 999 5452 (without extension pieces).



K6


**Install top cylinder head section**

Place top section in position.

Tighten it against cylinder head using press tools 999 5454 (2x).

Tighten top section from inside and out to **17 Nm** (13 ftlb).

Remove retainer (5453) and press tools (5454).



K7

**Install camshaft front seals**

Use drift 999 5449 and standard shaft 999 1801.

Oil seals.

Tap seals home.



## L. Timing belt assembly, reassembly

Special tools: 999 5199, -5433, -5450, -5455

L1

### Install oil pump


Use **new** gasket.

Use drift 999 5455 to install pump, using bolts as guides.

Pull in pump using crankshaft center nut.

**Note:** Do not let crankshaft turn, as this may damage valves.

Use thread locking compound (1 161 056-5) on bolts. Tighten bolts in star pattern to **10 Nm** (7 ftlb).




L2

### Install belt drive pulley on crankshaft

Install belt drive pulley using center nut and spacer.

Install oil thermostat housing, use **new** O-ring.


**Note:** Do not let crankshaft turn, as this may damage valves.



L3

### Install:

- inner timing belt cover
- coolant pump, using **new** gasket, tightening bolts alternately to **20 Nm** (15 ftlb).
- thermostat and thermostat housing, using **new** gasket.



L4


**Install upper timing belt cover**

Install camshaft pulleys, aligning timing marks as shown.

Insert two bolts in each pulley until they **just touch** the camshaft pulleys.

Remove upper timing belt cover.

**Note:** Check that camshaft bolt holes are centered in the oval holes.




152685

L5

**Install:**

- idler pulley, tighten to **25 Nm** (18 ftlb)
- tensioner pulley, grease surfaces of lever arm bushing, bolt and sleeve. Use grease P/N 1161246-2. Tighten to **40 Nm** (30 ftlb)
- tensioner/damper, tighten to **25 Nm** (18 ftlb)
- throw control washer (manual)



152686

L6

**Install timing belt**

Place belt over camshaft pulleys, around coolant pump and press over tensioner pulley.


Slacken two camshaft pulley bolts. Remove locking pin from belt tensioner.

Fix belt by tapping lightly (twice) with a plastic mallet between the camshaft pulleys and between the coolant pump and camshaft pulley.

Install third bolt in each pulley and tighten all bolts to **20 Nm** (15 ftlb).

Install upper transmission cover.

Install belt cover (snowguard).




152687

L7

**Remove locking tool**


Remove crankshaft locking tool (999 5451) and install **new** plug.

Remove camshaft locating tool (999 5452).



152 307





L8


#### Install camshaft rear seals

Use drift 999 5450.

Grease seals.

Press seals home.

If shaft end shows signs of wear, seal can be pressed another 2 mm in by turning tool sleeve.




L9

#### Install vibration damper

Install vibration damper using counterhold 5433.

Tighten center nut to 300 Nm (221 ftlb)

Remove counterhold and tighten bolt to 35 Nm (26 ftlb) plus 60°.



L10

#### Check markings

Turn crankshaft through two revolutions.

Check that timing marks on crankshaft and camshaft pulleys line up.


Install outer transmission cover.

## M. Cylinder block, refitting components

Special tools: 999 2520, -2810, -5112, -5297, -5428, -5429, -5459, -5464, 5593

M1


### Installation, intake side (B 6244, B 6254, B 6304)



- |   |                                     |
|---|-------------------------------------|
| 1. Wiring harness                           | 4. Intake manifold                  |
| 2. Injectors and fuel distribution manifold | 5. Knock sensors (2x)               |
| 3. Auxiliaries mounting bracket             | 6. LH engine mounting and bump stop |
|   | 7. Oil trap and hoses               |


M2

### Installation, exhaust side (B 6244, B 6254, B6304)




- |                       |                    |
|-----------------------|--------------------|
| 1. Exhaust manifold   | 5. Coolant pipe    |
| 2. RH engine mounting | 6. Ignition coils  |
| 3. Lifting lug        | 7. Sparkplug cover |
| 4. Heat shield        |                    |

M3

**Installation, rear of engine (B 6244, B 6254, B 6304)**

- 1. RPM sensor
- 2. Coolant pipe
- 3. Coolant hoses
- 4. Engine coolant temperature sensor

- 5. Camshaft position sensor (CMP sensor)
- 6. Lifting lug (999 5429)
- 7. Connector bracket



M4

**Install flywheel/carrier plate**

Use gear segment 999 5112 and special bolts 999 5593.

Install flywheel/carrier plate using three special bolts and tighten to **45 Nm (33 ftlb)**.

Install remaining standard bolts (new ones) and tighten to 45 Nm. Replace the three special bolts with standard bolts and tighten to: ..... **45 Nm (33 ftlb)**.


**Manual:**

Plus: ..... **.65°**

**Automatic:**

Plus: ..... **.50°**

M5



150 255

### Install gearbox and starter motor

*Installing gearbox:* See section 4 (43).

Install starter motor.

#### **Automatics:**

Install dipstick and tube.

Bolt torque converter to carrier plate, tightening bolts alternately to: ..... **50 Nm (37 ftlb)**

Install gearbox, tighten to: ..... **50 Nm (37 ftlb)**


#### **Manuels:**

First tighten bolts in rotation until pressure plate touches home.

Tighten clutch driven plate and pressure plate to ..... **30 Nm (22 ftlb)**

Install gearbox, tighten to ..... **50 Nm (37 ftlb)**

M6



150 262

### Install engine in car

Install engine as per appropriate steps in service manual: **Section 2 (20-22, 25-26)** (960)

# Index

	Step	Page		Step	Page
<b>Bearing end caps</b>			<b>Gudgeon pin bushings</b>		
Installation .....	J1–2	54	Inspection .....	F15	34
Removal .....	D4	27	Replacement .....	F13–16	33
<b>Camshaft pulleys</b>			<b>Gudgeon pins</b>		
Installation .....	L4	61	Inspection .....	F9–F10	32
Removal .....	C1	25	<b>Important</b> .....		
<b>Camshafts</b>			<b>Oil pump</b>		
Installation .....	K5	59	Cleaning/inspection .....	B9	23
Removal .....	C3	25	Installation .....	L1	60
<b>Carrier plate</b>			Removal .....	B8	23
Installation .....	M4	64	<b>Piston rings</b>		
Removal .....	A2	18	Axial clearance, inspection .....	F5	31
<b>Crank mechanism</b>			Installation .....	J8	56
Dismantling .....	D1–7	27	Removal .....	F4	28
Measurement .....	F1–6	30	<b>Pistons</b>		
Reassembly .....	J1–12	54	Cleaning/inspection .....	F4	31
<b>Crankshaft</b>			Diameter, measurement .....	F6	31
End float .....	J5	55	Installation .....	J9	56
Inspection .....	F1–3	30	Piston clearance .....	F7	32
Installation .....	J1–4	54	Removal .....	D6	28
Removal .....	D3–5	27	<b>Specifications</b> .....		
<b>Crankshaft seals</b>			<b>Tappets</b>		
Rear, installation .....	J6	55	Inspection .....	–	7
Rear, removal .....	D3	28	Installation .....	K2	58
<b>Cylinder block</b>			Removal .....	G1	35
Measurement .....	E1–3	29	<b>Thread inserts</b>		
<b>Cylinder head</b>			General .....	–	41
Assembly/installation .....	K1–7	58	Repairing threads .....	H1–7	41
Measurement/reconditioning .....	G1–20	35	<b>Timing belt and drive assembly</b>		
Removal/installation .....	C1–5	25	Assembly .....	L1–10	60
<b>Oil trap</b>			Dismantling .....	B1–15	21
Installation .....	M1	63	<b>Torque settings</b>		
Removal .....	A6	20	Table .....	–	11
<b>Flywheel</b>					
Installation .....	M4	64			
Removal .....	A2	18			

## Index, continued

	Step	Page
<b>Valves</b>		
Cleaning .....	G4	36
Installation .....	G18–19	40
Machining .....	G16–17	39
Removal .....	G2	35
<b>Valve guides</b>		
Replacement .....	G9–14	38
<b>Valve seats</b>		
Machining .....	G15	39
<b>Vibration damper</b>		
Installation .....	L9	62
Removal .....	B3	21